



SPAREWAYS

AIRBUS A330 - A340 CAPABILITY LIST

SOURCING / PROCUREMENT / REPAIR

Please address your requests and orders to sales@spareways.com
<http://www.spareways.net/>

PARTNUMBER	DESCRIPTION	ATA
0006487-801	PANEL OUTSIDE CONTROL	25
0076-00	EXTINGUISHER FIRE PORTABLE	26
007LG027D	LGCIU - LDG CTRL INTER UNIT	32
007LG027G	LGCIU - LDG CTRL INTER UNIT	32
007LG037E	LGCIU - LDG CTRL INTER UNIT	32
007LG038G	LGCIU - LDG CTRL INTER UNIT	32
007LG049G	LGCIU - LDG CTRL INTER UNIT	32
0102LM2GE	SENSOR TAT	34
0102ME2GE	SENSOR TAT	34
01N65900	TRANSMITTER ELT	25
01N65920	TRANSMITTER ELT	25
04P23-10	SOLENOID START	75
04P23-12	SOLENOID VALVE	75
04P23-8	SOLENOID VALVE	75
064-50000-2051	TRANSCEIVER VHF	23
064-50000-0505	TRANSCEIVER VHF	23
065-50000-0404	SFCC - SLAT FLAP CONTROL	27

065-50000-0509	SFCC - SLAT FLAP CONTROL	27
065-50001-0100	CSU - COMMAND SENSOR UNIT	27
065-50001-0200	CSU - COMMAND SENSOR UNIT	27
066-01127-1402	TRANSPONDER ATC	34
066-50007-0212	TRANSCEIVER RADIO ALTIMETER	34
066-50007-0222	TRANSCEIVER RADIO ALTIMETER	34
066-50007-0232	TRANSCEIVER RADIO ALTIMETER	34
066-50008-0405	TRANSCEIVER WEATHER RADAR	34
066-50008-0407	TRANSCEIVER WEATHER RADAR	34
066-50008-0409	TRANSCEIVER WEATHER RADAR	34
066-50012-0212	RECEIVER VOR MARKER	34
066-50012-1212	RECEIVER VOR MARKER	34
066-50013-0232	INTERROGATOR DME	34
066-50013-1222	INTERROGATOR DME	34
066-50014-0202	RECEIVER ADF	34
066-50014-1202	RECEIVER ADF	34
066-50029-1161	MMR - MULTI MODE RECEIVER	34
071-50001-8104	ANTENNA TCAS	34
071-50026-0200	ANTENNA RADIO ALTIMETER	34
071-50029-5502	ANTENNA GPS ACTIVE	34
07P95-1	VALVE PNEUMATIC RELAY	75
07P95-2	VALVE PNEUMATIC RELAY	75
07P95-3	VALVE PNEUMATIC RELAY	75
07P95-4	VALVE PNEUMATIC RELAY	75
07P95-7	VALVE PNEUMATIC RELAY	75
07P95-8	VALVE PNEUMATIC RELAY	75
0851HL	PROBE PITOT	34
0861ED	SENSOR ANGLE OF ATTACK	34
0861ED2	SENSOR ANGLE OF ATTACK	34
0871DP3	DETECTOR ICE	30

0871DP4	DETECTOR ICE	30
0871DP5	DETECTOR ICE	30
0871DP5-1	DETECTOR ICE	30
085878-04645	ACCUMULATOR BRAKE POWER	32
086339-04645	ACCUMULATOR BRAKE POWER	32
088256-04644	ACCUMULATOR BRAKE POWER	32
088259-04644	ACCUMULATOR BRAKE POWER	29
1001000-3	VALVE STARTER AIR	80
1001000-4	VALVE STARTER AIR	80
1-002-0102-0317	INVERTER STATIC	24
1-002-0102-1830	INVERTER STATIC	25
100-2500-03	CONTROLLER CDSS	23
100-2500-04	CONTROLLER CDSS	23
100-2513-090-08	CAMERA ASSY SURVEILLANCE	44
100-2513-105-08	CAMERA ASSY SURVEILLANCE	44
100-602198-003	HI GAIN ANTENNA	23
100-602199-002	BSU - BEAM STEERING UNIT	23
100-602200-001	DIPLEXER LOW NOISE AMPLIFIER	23
100-602200-004	DIPLEXER LOW NOISE AMPLIFIER	23
100-602221-000	PLATE ADAPTER	23
10072-04	INDICATOR FQI	28
10072-05	INDICATOR FQI	28
1007B0000-01	BRAKE WING TIP	27
1008A0100-01	SHAFT ASSY	27
10-100901-005	HARNESS UPPER	32
10-101101-000	HARNESS ELECTRICAL NLG	32
10-124701-002	HARNESS MLG	32
10-211101-000	LINK ADJUSTABLE	32
10-211301-000	ACTUATOR RETRACTION MLG	32
10-211301-001	ACTUATOR RETRACTION MLG	32

10-212501-000	ACTUATOR UNLOCK	32
10-212701-000	TRIMMER PITCH MLG	32
10-212702-000	TRIMMER PITCH MLG	32
10-212901-001	HARNESS STRUT MLG LH	32
10-213001-001	HARNESS STRUT MLG RH	32
10-213101-001	HARNESS STRUT MLG LH	32
10-213201-002	HARNESS STRUT MLG RH	32
10-213501-000	HARNESS BOGIE	32
10-213701-000	HARNESS BOGIE	32
10-609660-9	LEAD IGNITER	74
111-1-1100	SWITCH PRESSURE	38
1111A0000-01	VALVE SOLENOID	27
1108V0100-1	SOLENOID COMPR HEATING AND STARTER.	75
1108V0100-2	SOLENOID COMPR HEATING AND STARTER	75
1108V0100-3	SOLENOID COMPR HEATING AND STARTER	75
1109V0300	PNEUMATIC SOLENOID VALVE	75
1109V0300-1	PNEUMATIC SOLENOID VALVE	75
1109V0300-2	PNEUMATIC SOLENOID VALVE	75
1109V0300-3	PNEUMATIC SOLENOID VALVE	75
1110V0500-2	TURBINE VANE BLADE COOLING VALVE	75
1110V0500-3	TURBINE VANE BLADE COOLING VALVE	75
1110V0500-4	TURBINE VANE BLADE COOLING VALVE	75
1110V0500-5	TURBINE VANE BLADE COOLING VALVE	75
1110V0500-6	TURBINE VANE BLADE COOLING VALVE	75
1110V0700-3	TURBINE VANE BLADE COOLING VALVE	75
1110V0700-4	TURBINE VANE BLADE COOLING VALVE	75
1110V0700-5	VALVE AIR SHUT OF TURBINE BLADE - VANE	75
1115V0300-1	VALVE BLEED STG 9	75
1115V0300-4	VALVE BLEED STG 9	75
1115V0300-5	VALVE BLEED STG 9	75

1115V0300-6	VALVE BLEED STG 9	75
1115V0700	VALVE BLEED STG 9	75
1115V0700-4	VALVE BLEED STG 9	75
1115V0700-5	VALVE START STABILITY BLEED	75
1115V0700-6	VALVE BLEED STG 9	75
1115V0700-7	VALVE START STABILITY BLEED	75
1115V0700-8	VALVE START STABILITY BLEED	75
1115V0700-9	VALVE BLEED STG 9	75
1115V0700-10	VALVE START STABILITY BLEED	75
11469-00	HEATER UNIT FAN	21
1152394-2	BRACKET EMERGENCY TRANSMITTER	25
1153426-1M563	EMERGENCY LOCATOR TRANSMITTER	25
11698-000	HEAT EXCHANGER AIR - OIL	24
11-811538-1	EXCHANGER PRECOOLER	36
120D2	INDICATOR CLOGGING	21
1211575-001	ACTUATOR RAM AIR TURBINE	29
1211575-002	ACTUATOR RAM AIR TURBINE	29
1218-100	SWITCH PRESSURE	21
123100-3	PDU - POWER DRIVE UNIT	25
12428	VALVE NON RETURN	21
1266-100	SWITCH DIFFERENTIAL PRESSURE	52
1266-200	SWITCH DIFFERENTIAL PRESSURE	21
12664	VALVE CHECK	21
12698-000	HEAT EXCHANGER-AIR-OIL	24
129100-1009	PDU POWER DRIVE UNIT	25
12D0024	VALVE LANDING GEAR BYPASS	32
1320A0000-01	VALVE TRIM AIR	21
1320A0000-02	VALVE TRIM AIR	21
1386B0000-02	SERVOCONTROL SPOILER	27
1386C0000-01	SERVOCONTROL SPOILER	27

1386D0000-01	SERVOCONTROL SPOILER	27
1387C0000-01	SERVOCONTROL SPOILER	27
1387D0000-01	SERVOCONTROL SPOILER	27
1390A0100-01	ADAPTER ASSY PPU	27
1394A0000-01	VALVE TEMPERATURE CONTROL	21
1404001-1	SPRING STRUT MLG	32
1404020-1	SPRING STRUT MLG	32
147100-115	LATCH YZ CENTER	25
15622-000	HEAT EXCHANGER AIR - OIL	79
1567A0000-01	VALVE SELECTOR	52
157605-2	ACTUATOR RAM AIR INLET	21
157605-3	ACTUATOR RAM AIR INLET	21
160-11001-990	SUNVISOR WINDSHIELD LH	25
1603A0000-02	EXCHANGER HEAT RAM	21
160424-2	REGULATOR	49
1604A0000-02	REHEATER CONDENSER	21
1605A0000-02	EXTRACTOR WATER	21
1610000-10	LOCKING ACTUATOR FAN REVERSER	78
1610000-11	LOCKING ACTUATOR FAN REVERSER	78
1610000-13	LOCKING ACTUATOR FAN REVERSER	78
1610000-17	LOCKING ACTUATOR FAN REVERSER	78
1616A0000-02	SELECTOR TEMPERATURE	21
1618C0000-02	HEATER CONTROLLER	21
1618C0000-03	HEATER CONTROLLER	21
1671220-00	SEAT FOURTH OCCUPANT	25
1700667D	GAPCU-GROUND AUXILIARY POWER	24
1701401A	GEARBOX ASSY - TURBINE LOWER	29
1702934B	RAT - RAM AIR TURBINE	29
1702934C	RAT - RAM AIR TURBINE	29
1702934D	RAT - RAM AIR TURBINE	29

1702934E	RAT - RAM AIR TURBINE	29
1709121	IDG INTEGRATED DRIVE GENERATOR	24
1720399	ACTUATOR RAM AIR TURBINE	29
173628-101	DIPLEXER-LOW NOISE AMPLIFIER	23
1742A0000-02	ACTUATOR DOOR NLG	32
17A717-03-00	LINEAR ACCELEROMETER	31
18330915-1	GAGE NITROGEN PRESSURE	29
190306-3	GUIDE ENTRANCE	25
190307-51	GUIDE ENTRANCE	25
190307-7	GUIDE ENTRANCE	25
190307-71	GUIDE ENTRANCE	25
190316-3	TRACK ASSY ROLLER	25
190317-15	TRACK ASSY ROLLER	25
190317-17	TRACK ASSY ROLLER	25
190317-9	TRACK ASSY ROLLER	25
190318-21	TRACK ASSY ROLLER	25
190340-1	LATCH	25
190340-3	LATCH	25
190576-3	MAT ASSY-BALL	25
1964A0000-03	SERVOCONTROL RUDDER	27
1964A0000-04	SERVOCONTROL RUDDER	27
196PN01Y02	RUDDER TRIM INDICATOR	27
1982660116	DMC - DISPLAY MANAGEMENT CO	31
1982A0000-01	TRANSDUCER DIFFERENCE PRESSURE	27
1X2455912-00	LIGHT CARGO COMPARTMENT	33
1X2455912-10	LIGHT CARGO COMPARTMENT	33
2000013-01-001	HARNESS ASSY	25
2000013-03-001	HARNESS ASSY	25
2000013-11-001	HARNESS ASSY	25
2000013-13-001	HARNESS ASSY	25

20097-0201	COMPENSATOR	28
201042561	VALVE DELAY	32
20130-0101	PROBE WING TANK	28
20130-0102	PROBE WING TANK OUTER	28
20130-0103	PROBE WING TANK OUTER	28
20130-0104	PROBE WING TANK OUTER	28
20130-0105	PROBE WING TANK OUTER	28
20130-0106	PROBE WING TANK OUTER	28
20130-0107	PROBE WING TANK	28
20130-0108	PROBE WING TANK INNER	28
20130-0109	PROBE WING TANK INNER	28
20130-0110	PROBE WING TANK INNER	28
20130-0111	PROBE WING TANK INNER	28
20130-0112	PROBE WING TANK INNER	28
20130-0113	PROBE WING TANK INNER	28
20130-0114	PROBE WING TANK	28
20130-0116	PROBE WING TANK	28
20130-0119	PROBE WING TANK INNER	28
20130-0215	PROBE WING TANK	28
20130-0218	PROBE WING TANK INNER	28
201480002-020	TRIMMER PITCH MLG	32
201481001	ACTUATOR UNLOCK	32
201481001-005	ACTUATOR UNLOCK	32
20151-0101	PROBE FQI	28
20151-0104	PROBE FQI	28
20151-0105	PROBE FQI	28
20151-0106	PROBE FQI	28
20151-0107	PROBE FQI	28
20151-0108	PROBE FQI	28
20151-0109	PROBE FQI	28

20151-0110	PROBE FQI	28
20151-0111	PROBE FQI	28
20151-0112	PROBE FQI	28
20151-0113	PROBE FQI	28
20151-0114	PROBE FQI	28
20151-0115	PROBE FQI	28
20151-0116	PROBE FQI	28
20151-0117	PROBE FQI	28
20151-0118	PROBE FQI	28
20151-0120	PROBE FQI	28
20151-0121	PROBE FQI	28
20151-0122	PROBE FQI	28
20151-0123	PROBE FQI	28
20151-0124	PROBE FQI	28
20151-0125	PROBE FQI	28
20151-0204	PROBE FQI	28
20151-0205	PROBE FQI	28
20151-0219	PROBE FQI	28
2040029-102	VALVE DUAL FLOW	47
2041214-0401	TRAY MOUNTING	34
2041220-0424	CONTROL UNIT WEATHER RADAR	34
2041220-0409	RADAR CONTROL PANEL	34
2041220-3231	CONTROL UNIT WEATHER RADAR	34
2041444-0404	DRIVE WEATHER RADAR ANTENNA	34
2041444-0424	DRIVE WEATHER RADAR ANTENNA	34
2041446-0401	ANTENNA WEATHER RADAR	34
2050120-101	GATE VALVE	47
2059A0000-01	PANEL CONTROL TEMPERATURE	25
2068599-0705	PLATE	34
20781-02	MOTOR AUTO	21

20792-01AA	VALVE OUTFLOW	21
20792-02AC	VALVE OUTFLOW	21
20792-03AC	VALVE OUTFLOW	21
20792-04AC	VALVE OUTFLOW	21
20792-10BA	VALVE OUTFLOW	21
20793-01AA	CONTROLLER PRESSURE	21
20793-02AB	CONTROLLER PRESSURE	21
20793-30BA	CONTROLLER PRESSURE	21
20793-31BB	CONTROLLER PRESSURE	21
20793-41BC	CONTROLLER PRESSURE	21
20793-42BC	CONTROLLER PRESSURE	21
20793-42BD	CONTROLLER PRESSURE	21
20K0032	VALVE NON RETURN	28
2100-1020-02	CVR - COCKPIT VOICE RECORDER	23
2100-1025-02	SSCVR	23
2100-1226-02	CVR - COCKPIT VOICE RECORDER	23
2100-4043-02	SSFDR - SOLID STATE FDR	31
2100-4245-00	SSFDR - SOLID STATE FDR	31
21071-02AC	BOX-ELECTRONIC	21
21071-03AC	BOX-ELECTRONIC	21
210TS07Y01	LEVER-CONTROL.LANDING GEA	32
212675-0	ROPE-EMERGENCY ESCAPE	25
21275-02AC	VALVE-OUTFLOW	21
21275-03AC	VALVE-OUTFLOW	21
2130161-101	CONVERTER-OZONE, FTIS	21
215TS07Y00	LEVER-CONTROL.LANDING GEA	32
215TS07Y01	LEVER-CONTROL.LANDING GEA	32
2-1578-1	BRAKE ASSY	32
2-1578-1OPT2	BRAKE ASSY	32
2-1578-2	BRAKE ASSY	32

2-1578-2OPT1	BRAKE ASSY	32
2-1578-2OPT2	BRAKE ASSY	32
2-1578-3	BRAKE ASSY	32
2-1578-4	BRAKE ASSY	32
2-1578-6	BRAKE ASSY	32
2-1578-7	BRAKE ASSY	32
2-1577-1	BRAKE ASSY	32
2-1577-1	BRAKE ASSY	32
2-1577-1OPT1	BRAKE ASSY	32
2-1577-1OPT1	BRAKE ASSY	32
2-1577-1OPT2	BRAKE ASSY	32
2-1577-1OPT2	BRAKE ASSY	32
2-1577-2	BRAKE ASSY	32
2-1577-2	BRAKE ASSY	32
2-1577-2OPT1	BRAKE ASSY	32
2-1577-2OPT2	BRAKE ASSY	32
2-1577-2OPT2	BRAKE ASSY	32
2-1577-3	BRAKE ASSY	32
2-1577-3	BRAKE ASSY	32
2-1577-3OPT1	BRAKE ASSY	32
2-1577-3OPT2	BRAKE ASSY	32
2-1577-4	BRAKE ASSY	32
2-1577-4	BRAKE ASSY	32
2-1577-4OPT1	BRAKE ASSY	32
2-1577-4OPT2	BRAKE ASSY	32
2-1577-6	BRAKE ASSY	32
2-1577-7	BRAKE ASSY	32
2-1577-7	BRAKE ASSY	32
2-1577-8	BRAKE ASSY	32
2-1577-8	BRAKE ASSY	32

2-1577-9	BRAKE ASSY	32
2-1577-9	BRAKE ASSY	32
2-1705	BRAKE-MULTIPLE DISK	32
221-0503-523	SLEEVE ENGINE LH N1-3	78
221-0503-523-3	SLEEVE ENGINE LH N1-3	78
221-0503-524	SLEEVE ENGINE LH N1-3	78
221-0503-524-3	SLEEVE ENGINE LH N1-3	78
221-0503-525	SLEEVE ENGINE LH N2	78
221-0503-526	SLEEVE ENGINE RH N2	78
221-0520-65	LATCH FAN REVERSER	78
221-0558-521	DOOR AASSY BLOCKER	78
221-0558-523	DOOR AASSY BLOCKER	78
221-0558-524	DOOR AASSY BLOCKER	78
221-0558-525	DOOR AASSY BLOCKER	78
221-0558-527	DOOR AASSY BLOCKER	78
221-0558-528	DOOR AASSY BLOCKER	78
221-0558-529	DOOR AASSY BLOCKER	78
221-0558-531	DOOR AASSY BLOCKER	78
221-0558-532	DOOR AASSY BLOCKER	78
221-0558-541	DOOR AASSY BLOCKER	78
221-0558-543	DOOR AASSY BLOCKER	78
221-0558-544	DOOR AASSY BLOCKER	78
221-0580-504	HINGE	78
221-0620-507	HINGE	78
221-0701-507	CLIP HOLD OPEN ROD	78
221-0727-113	DOOR	78
221-0727-73	FAN DOOR	78
221-0727-89	FAN DOOR	78
221-0765-509	HANDLE	78
221-0765-510	HANDLE	78

221-0765-511	HANDLE	78
221-0765-512	HANDLE	78
221-0765-514	HANDLE FAN REVERSER RH	78
221-0778-521	CASCADE	78
221-0778-527	CASCADE	78
221-0778-529	CASCADE	78
221-0778-531	CASCADE	78
221-0778-532	CASCADE	78
221-0778-541	CASCADE	78
221-0778-543	CASCADE	78
221-0778-544	CASCADE	78
221-0778-545	CASCADE	78
221-0778-547	CASCADE	78
221-0778-548	CASCADE	78
221-0778-549	CASCADE	78
221-0778-551	CASCADE	78
221-0778-552	CASCADE	78
221-0779-507	CASCADE ASSY	78
221-0779-508	CASCADE	78
221-0779-517	CASCADE	78
221-0779-518	CASCADE	78
221-0779-519	CASCADE	78
221-0779-520	CASCADE	78
221-0779-521	CASCADE	78
221-0779-522	CASCADE	78
221-0779-527	CASCADE ASSY	78
221-4050-29	INLET COWL (PW4000)	71
221-4050-31	INLET COWL (PW4000)	71
221-4050-49	INLET COWL (PW4000)	71
221-4050-511	INLET COWL (PW4000)	71

221-4050-513	INLET COWL (PW4000)	71
221-4050-515	INLET COWL (PW4000)	71
221-4050-523	INLET COWL (PW4000)	71
221-4050-525	INLET COWL (PW4000)	71
221-4050-53	INLET COWL (PW4000)	71
221-4050-57	INLET COWL (PW4000)	71
221-4050-63	NOSE COWL ENGINE N1-3	71
221-4050-83	INLET COWL (PW4000)	71
221-4050-85	INLET COWL	71
221-4056-11	DUCT INLET COWL ANTI-ICE	30
221-4056-17	DUCT INLET COWL ANTI-ICE	30
221-4061-159	PANEL ASSY	71
221-4061-163	PANEL ASSY	71
221-4061-213	PANEL ASSY	71
221-4061-331	PANEL ASSY	71
221-4144-501	DUCT FAN REVERSER RH	78
221-4144-503	DUCT FAN REVERSER RH	78
221-4144-505	DUCT FAN REVERSER RH	78
221-4145-503	DUCT FAN REVERSER LH	78
221-4145-505	DUCT FAN REVERSER LH	78
221-4164-519	DOOR FAN REVERSER LH	78
221-4169-501	LINK	78
221-4215-501	STRUT ASSY	78
221-4215-503	STRUT ASSY	78
221-4266-507	BAR	78
221-4266-511	DUCT AXIAL COOLING	78
221-4543-501	CASCADE	78
221-4543-502	CASCADE	78
221-4543-503	CASCADE	78
221-4543-504	CASCADE	78

221-4543-507	CASCADE	78
221-4543-508	CASCADE	78
221-5061-505	BELLMOUTH ASSEMBLY (TAIL ENGINE)	71
221-5061-507	BELLMOUTH ASSEMBLY (TAIL ENGINE)	71
221-5123-1001	FAN REVERSER ENGINE N2 LH	78
221-5123-1003	FAN REVERSER ENGINE N2 RH	78
221-5123-335	FAN REVERSER TAIL ENGINE N2 RH	78
221-5123-335-3	FAN REVERSER ENGINE N2 RH	78
221-5123-453	FAN REVERSER TAIL ENGINE N2 RH	78
221-5123-453-3	FAN REVERSER ENGINE N2 RH	78
221-5123-515-3	FAN REVERSER ENGINE N2 RH	78
221-5123-517	FAN REVERSER TAIL ENGINE N2 RH	78
221-5123-517-3	FAN REVERSER ENGINE N2 RH	78
221-5123-519	FAN REVERSER TAIL ENGINE N2 LH	78
221-5123-519-3	FAN REVERSER ENGINE N2 LH	78
221-5123-525	FAN REVERSER TAIL ENGINE N2 LH	78
221-5123-525-3	FAN REVERSER ENGINE N2 LH	78
221-5123-527	FAN REVERSER TAIL ENGINE N2 RH	78
221-5123-527-3	FAN REVERSER ENGINE N2 RH	78
221-5123-533	FAN REVERSER TAIL ENGINE N2 LH	78
221-5123-533-3	FAN REVERSER ENGINE N2 LH	78
221-5123-535	FAN REVERSER TAIL ENGINE N2 RH	78
221-5123-535-3	FAN REVERSER ENGINE N2 RH	78
221-5123-541	FAN REVERSER TAIL ENGINE N2 LH	78
221-5123-541-3	FAN REVERSER ENGINE N2 LH	78
221-5123-543	FAN REVERSER TAIL ENGINE N2 RH	78
221-5123-543-3	FAN REVERSER ENGINE N2 RH	78
221-5123-549	FAN REVERSER ENGINE N2 LH	78
221-5123-549-3	FAN REVERSER ENGINE N2 LH	78
221-5123-551	FAN REVERSER ENGINE N2 RH	78

221-5123-551-3	FAN REVERSER ENGINE N2 RH	78
221-5123-553	FAN REVERSER ENGINE N2 LH	78
221-5123-555	FAN REVERSER ENGINE N2 RH	78
221-5125-1001	FAN REVERSER ENGINE N1 LH	78
221-5125-1003	FAN REVERSER ENGINE N1 RH	78
221-5125-1005	FAN REVERSER ENGINE N3 LH	78
221-5125-1007	FAN REVERSER ENG. 3 RH	78
221-5125-521	FAN REVERSER ENGINE N1-3 LH	78
221-5125-521-3	FAN REVERSER ENGINE N1 LH	78
221-5125-523	FAN REVERSER ENGINE N1-3 RH	78
221-5125-523-3	FAN REVERSER ENGINE N1 RH	78
221-5125-525-3	FAN REVERSER ENGINE N3 LH	78
221-5125-527	FAN REVERSER ENGINE N1-3 RH	78
221-5125-527-3	FAN REVERSER ENGINE N3 RH	78
221-5125-529-3	FAN REVERSER ENGINE N1 LH	78
221-5125-533	FAN REVERSER ENGINE N1-3 LH	78
221-5125-533-3	FAN REVERSER ENGINE N3 LH	78
221-5125-543	FAN REVERSER ENGINE N1-3 LH	78
221-5125-543-3	FAN REVERSER ENGINE N1 LH	78
221-5125-545	FAN REVERSER ENGINE N1-3 RH	78
221-5125-545-3	FAN REVERSER ENGINE N1 RH	78
221-5125-547	FAN REVERSER ENGINE N1-3 LH	78
221-5125-547-3	FAN REVERSER ENGINE N3 LH	78
221-5125-549	FAN REVERSER ENGINE N1-3 RH	78
221-5125-549-3	FAN REVERSER ENGINE N3 RH	78
221-5125-553-3	FAN REVERSER ENGINE N1 RH	78
221-5125-557-3	FAN REVERSER ENGINE N3 RH	78
221-5125-559-3	FAN REVERSER ENGINE N1 LH	78
221-5125-563-3	FAN REVERSER ENGINE N3 LH	78
221-5125-569-3	FAN REVERSER ENGINE N1 RH	78

221-5125-573-3	FAN REVERSER ENGINE N3 RH	78
221-5125-575	FAN REVERSER ENGINE N1 LH	78
221-5125-577	FAN REVERSER ENGINE N1 RH	78
221-5125-579	FAN REVERSER ENGINE N3 LH	78
221-5125-579-3	FAN REVERSER ENGINE N1-3 LH	78
221-5125-581	FAN REVERSER ENGINE N3 RH	78
221-5125-581-3	FAN REVERSER ENGINE N1-3 RH	78
221-5211-501	FAIRING DIVERTER	71
221-5211-503	FAIRING DIVERTER	71
221-5380-501	DOOR FAN ACCESS FAN LH	71
221-5381-501	DOOR FAN ACCESS FAN RH	71
221-5391-501	DOOR FAN ACCESS FAN LH	71
221-5392-501	DOOR FAN ACCESS FAN RH	71
221-6101-501	COWL ASSY INLET	71
221-6151-501	DOOR FAN COWL LH	71
221-6152-501	DOOR FAN COWL LH	71
221D0029-9	LATCH KEEPER ASSEMBLY	78
221D0064-3	LATCH KEEPER ASSEMBLY	78
221D0081-517	ROD ASSY HOLD OPEN	78
221D0081-519	ROD ASSY HOLD OPEN	78
22286090-103	SERVOVALVE	27
22286090-104	SERVOVALVE	27
222CE06L13Y10	SSPCM - SOLID STATE POWER	24
2230A0000-01	CHAMBER AIR PLENUM	21
2234340-02-02	FDIMU-FLIGHT DATA INTERFA	31
2240A0000-01	ACTUATOR ROTARY	27
2240A0000-02	ACTUATOR ROTARY	27
2241A0000-01	ACTUATOR ROTARY	27
2241A0000-02	ACTUATOR ROTARY	27
2241L0000-02	ACTUATOR ROTARY	27

2243800-362	QAR - QUICK ACCESS RECORDER	31
2243800-73	QAR - QUICK ACCESS RECORDER	31
2253500-06	DU - DISPLAY UNIT	46
2253600-03-03	PROCESSOR UNIT	46
229065	PUMP FUEL FEED	28
229066	CANISTER FWD	28
22C220120370005	CONTAINER ASSY CHEMICAL	35
22C220150020005	CONTAINER ASSY CHEMICAL	35
22C220240370005	CONTAINER ASSY CHEMICAL	35
230QA01	CUDU - CURRENT UNBALANCE	29
2330A0001K01	HEATER UNIT ELECTRICAL	21
2368-501	OUTLET AIR BLACK	21
236-508	REFRIGERATION UNIT AIR CHILLER 4500 BTU	25
236-8	REFRIGERATION UNIT AIR CHILLER 4500 BTU	25
2403-89	ANTENNA VDR	23
241-226-000-021	RCC - REMOTE CHARGE CONVERT	77
24173	PANEL CODING	31
2438-89	ANTENNA VHF	23
2438-89-00	ANTENNA VDR	23
24E507009G03	HEATER WATER	25
252CA01C1-02Y1	CONTACTOR THREE POLE	38
2598E	TRANSFORMER LIGHTING	33
2610132-3	BRAKE ASSY	32
2610132-4	BRAKE ASSY	32
2610132-5	BRAKE ASSY	32
2610132-6	BRAKE ASSY	32
2610181-2	WHEEL MLG	32
2610181-3	WHEEL MLG	32
2610181-4	WHEEL MLG	32
2610181-5	WHEEL MLG	32

2610181-6	WHEEL MLG	32
2610182-3	BRAKE ASSY	32
2610182-4	BRAKE ASSY	32
2610182-5	BRAKE ASSY	32
2610182-6	BRAKE ASSY	32
2610534	WHEEL OUTER HALF	32
2610666	HUBCAP ASSY	32
2612117-1	WHEEL OUTER ASSY	32
2612152-1	BRAKE ASSY	32
2612152-2	BRAKE ASSY	32
2612152-3	BRAKE ASSY	32
2612202-1	BRAKE ASSY	32
2612202-2	BRAKE ASSY	32
2612202-3	BRAKE ASSY	32
2612202-4	BRAKE ASSY	32
2616604-1	WHEEL INNER ASSY	32
2624-82	ANTENNA ELT	25
2632-82	ANTENNA ELT	25
2695A0000-01	SENSOR PRESSURE	21
2698A0000-01	SENSOR PRESSURE	21
2699A0000-01	SENSOR PRESSURE	21
271-200-025-207	EIVMU - ENGINE INTERFACE	73
271-200-025-304	EIVMU - ENGINE INTERFACE	73
271-200-027-305	EIVMU - ENGINE INTERFACE	73
272-381225-00	NIPPLE FILL HEATED	30
272-381226-00	NIPPLE OVERFLOW HEATED	30
27-457	RUDDER TRIM CONTROL SWITC	27
2813A0001K01	PANEL CONTROL TEMPERATURE	25
2-8181-2	VALVE SAFETY	29
2831-52	HEATER	21

2982T100-3	LATCH	25
2983T100-1	LATCH	25
2985T100-1	LATCH	25
2987T100-101	LATCH	25
2988T100-103	LATCH	25
2995-402-00-10	SHUNT	24
2LA004626-00	LIGHT CREW READING	33
2LA005303-05	LIGHT UNIT STROBE	33
2LA005308-05	LIGHT UNIT STROBE	33
2LA403702-02	LIGHT-NAVIGATION REAR DUAL	33
2LA455010-00	LIGHT ANTICOLLISION	33
2S7138	VALVE CHECK APU BLEED	36
3-1509-2	WHEEL MLG	32
3-1509-3	WHEEL MLG	32
3-1510-1	WHEEL NLG	32
3-1546	WHEEL MLG	32
3-1546	WHEEL MLG	32
3-1546-51	WHEEL MLG FITTED WITH TIRE	32
3-1546-56	WHEEL MLG FITTED WITH TIRE	32
3-1547	WHEEL NLG	32
3-1547	WHEEL NLG	32
3-1547-51	WHEEL NLG FITTED WITH TIRE	32
3-1547-52	WHEEL NLG FITTED WITH TIRE	32
3-1596	WHEEL NLG	32
3-1596	WHEEL NLG FITTED WITH TIRE	32
3-1596-51	WHEEL NLG FITTED WITH TIRE	32
3-1596-52	WHEEL NLG FITTED WITH TIRE	32
300-046-896	FTSP FLOOR TEMPERATURE SENSOR	25
300-048-454	VERSATILE HEATING CONTROL	21
300-056-000	IPCU - ICE PROTECTION CONTROLLER	30

300-067-265	IPCU - ICE PROTECTION CONTROLLER	25
3001-01-111	LINEAR ACCELEROMETER	31
30-1706-1	LIGHT READY FOR FUEL	28
3022053-000	PUMP HYDRAULIC	29
3022053-001	PUMP HYDRAULIC	29
30-2671-2	LIGHT ENGINE SCAN	33
30-2671-7	LIGHT ASSY-ENGINE SCAN LH	33
30-2671-8	LIGHT ASSY-ENGINE SCAN RH	33
30-2672-2	LIGHT WING SCAN	33
30-2672-3	LIGHT ASSY WING SCAN LH	33
30-2672-4	LIGHT ASSY WING SCAN RH	33
304643-2	MODULE MEMORY.APU	49
307892	VALVE NON RETURN	28
3110-89	ANTENNA VOR	34
31115-060	SERVOCONTROL RUDDER	27
31115-080	SERVOCONTROL RUDDER	27
319545-75	VALVE LOAD SOLENOID	49
321000M03	SSTU - SIDE STICK TRANSDUCER	27
321200M02	SSTU - SIDE STICK TRANSDUCER	27
3214-62	EPSU - EMERGENCY POWER SUPPLY	33
3214-62-10	EPSU - EMERGENCY POWER SUPPLY	33
3214-62-20	EPSU - EMERGENCY POWER SUPPLY	33
3214-91	ASPSU - AUTONOMOUS STANDBY POWER	52
3214-92	ASPSU - AUTONOMOUS STANDBY POWER	52
3022090-234	SOLENOID VALVE	29
321-211-703-0	LEVER	78
321-211-752-0	LEVER	78
321-211-753-0	LEVER	78
321-310-011-0	DOOR PIVOTING UPPER LH	78
321-310-012-0	DOOR PIVOTING LOWER LH	78

321-310-013-0	DOOR PIVOTING LOWER LH	78
321-310-061-0	DOOR PIVOTING UPPER RH	78
321-310-062-0	DOOR PIVOTING UPPER RH	78
321-310-063-0	DOOR PIVOTING UPPER RH	78
321-322-900-0	FITTING ATTACHMENT	78
321-322-900-6	FITTING ATTACHMENT	78
321-360-009-0	DOOR PIVOTING LOWER LH	78
321-360-010-0	DOOR PIVOTING LOWER LH	78
321-360-012-0	DOOR PIVOTING LOWER LH	78
321-360-013-0	DOOR PIVOTING LOWER LH	78
321-360-014-0	DOOR PIVOTING LOWER LH	78
321-360-059-0	DOOR PIVOTING LOWER RH	78
321-360-060-0	DOOR PIVOTING LOWER RH	78
321-360-062-0	DOOR PIVOTING LOWER RH	78
321-360-063-0	DOOR PIVOTING LOWER RH	78
321-360-064-0	DOOR PIVOTING LOWER RH	78
321-360-801-0	FITTING	78
321-400-703-0	ACTUATOR - HYDRAULIC DOOR	78
321-400-704-0	ACTUATOR - HYDRAULIC DOOR	78
321-400-705-0	ACTUATOR - HYDRAULIC DOOR	78
321-402-502-0	PIPE	78
3210-005DB067	INFLIGHT TRASH COMPACTOR ASSY	25
3210-005WB001	INFLIGHT TRASH COMPACTOR ASSY	25
3210-005WB013	INFLIGHT TRASH COMPACTOR ASSY	25
3210-005WB016	INFLIGHT TRASH COMPACTOR ASSY	25
3210-005WB084	INFLIGHT TRASH COMPACTOR ASSY	25
3210-005WB084	INFLIGHT TRASH COMPACTOR ASSY	25
3210-005WB091	INFLIGHT TRASH COMPACTOR ASSY	25
3210-005WB093	INFLIGHT TRASH COMPACTOR ASSY	25
3202176-2	VALVE CHECK STAGE 8	36

3202176-3	VALVE CHECK STAGE 8	36
322200-1M00	HANDWHEEL NOSEWHEEL STEERING	32
322200-2M00	HANDWHEEL NOSEWHEEL STEERING	32
3224-50	WARMER FOOT	25
3284-14	CONTROL UNIT AUTOMATIC	26
3290476-3	VALVE SURGE CONTROL	49
3290476-4	VALVE SURGE CONTROL	49
3290476-5	VALVE SURGE CONTROL	49
3290488-5	VALVE ANTI-ICING	21
3290718-1	VALVE OVERPRESSURE	36
3291544-5	VALVE BLEED.AIR	49
3294-10-1	LIGHT CARGO COMPARTMENT	33
3294-10-2	LIGHT CARGO COMPARTMENT	33
32C220342020005	CONTAINER ASSY CHEMICAL	35
330400-1M00	CONTROL UNIT THROTTLE	73
330400M01	CONTROL UNIT THROTTLE	76
334VZ01Y00	SWITCH PUSHBUTTON	31
33600005-3	EXTINGUISHER FIRE APU	26
342300M00	TRANSDUCER UNIT	27
345000-1M00	PEDAL DAMPER & FRICTION UNIT	27
34600028-1	EXTINGUISHER FIRE ENGINE	26
350100-1	SPLITTER	25
3540000-4	SENSOR TEMPERATURE	28
3552AAAWAACXCD	CYLINDER OXYGEN PORTABLE	35
3552CAAAAACXCD	BOTTLE EMERGENCY OXYGEN	35
3614295-1	VALVE COOLING	49
3614295-2	VALVE COOLING	49
3614295-3	VALVE COOLING	49
3616960-2	FAN ASSY	49
3616960-3	FAN ASSY	49

367-359-005	ICU - IGGS CONTROLLER UNIT	47
3710-00-00	FDU - FIRE DETECTION UNIT	26
3711-00	FDU - FIRE DETECTION UNIT	26
3735B010000	EXCHANGER PRECOOLER	36
3735C010000	EXCHANGER PRECOOLER	36
3735C020000	EXCHANGER PRECOOLER	36
38000-290	VALVE SHUTOFF	25
3830032-105	VALVE OIL COOLER BYPASS	79
3831162-104	SOLENOID HOUSING	79
3861106-1	CLUTCH STARTER	49
3861106-2	CLUTCH STARTER	49
3876049-4	VALVE FUEL SOLENOID	49
3876132-6	CABLE ASSY IGNITION	49
3876132-7	CABLE ASSY IGNITION	49
3876186-4	SWITCH LOW OIL PRESSURE	49
3876187-4	SWITCH LOW FUEL PRESSURE	49
3876188-2	SWITCH QUANTITY LOW OIL	49
3876195-8	EXCITER IGNITION	49
3876195-9	EXCITER IGNITION	49
3876255-2	SENSOR PRESSURE	49
3876337-1	MODULE ASSY PRESSURE	49
3876344-4	SWITCH OIL QUANTITY	49
3876379-1	SWITCH QUANTITY LOW OIL	49
3881000-6	PUMP OIL	49
3881000-7	PUMP OIL	49
3881691-1	SOLENOID VALVE DE OIL	49
3883240-6	CONTROL UNIT FUEL	49
3883240-7	CONTROL UNIT FUEL	49
3883297-6	DIVIDER ASSY FLOW	49
3883297-7	DIVIDER ASSY FLOW	49

3883297-9	DIVIDER ASSY FLOW	49
3883453-1	NOZZLE FUEL	49
3886188-3	ACTUATOR IGV	49
3888058-5	EXCITER IGNITION	49
3888058-7	EXCITER IGNITION	49
3888217-3	MOTOR STARTER	49
3888217-4	MOTOR STARTER	49
3888394-210102	ECB - ELECTRONIC CONTROL BOX	49
3888394-210103	ECB - ELECTRONIC CONTROL BOX	49
3888394-310104	ECB - ELECTRONIC CONTROL BOX	49
3888458-3	HARNESS ASSY WIRING	49
38E93-5	VALVE-CONTROL WING ANTI ICE	30
38E93-6	VALVE-CONTROL WING ANTI ICE	30
388D010000	THERMOSTAT	36
3901340	PUMP JET	28
3957A0000-02	VALVE ISOLATION	21
3964A0000K01	SENSOR TEMPERATURE	21
3968B0000K01	EXCHANGER HEAT	21
3969A0000K01	CONVERTER OZONE	21
397B030000	THERMOSTAT SOLENOID	36
398B050000	THERMOSTAT SOLENOID	36
398B060000	THERMOSTAT SOLENOID	36
398E020000	THERMOSTAT SOLENOID	36
398E030000	THERMOSTAT SOLENOID	36
4007001	MOTOR HYDRAULIC	27
40070-01	MOTOR HYDRAULIC	27
400SV01Y01	SLEEVE PUSHBUTTON SWITCH	26
401100-1	LATCH DOORSILL	25
401100-3	LATCH DOORSILL	25
4020Q10-2	PRESS UNIT AIR	29

402100-1	LATCH DOORSILL	25
402100-3	LATCH DOORSILL	25
402-188-3	RELAY GLIDE ANTENNAS	34
402310-1	ACTUATOR	25
402310-3	ACTUATOR	25
402310-5	ACTUATOR	25
402310-7	ACTUATOR	25
402330-3	ACTUATOR	25
405100-1	ROLLER DOORSILL	25
405CH	BATTERY	24
4063-18139	VALVE CHECK	21
4063-18140-01	VALVE CHECK	21
4063-18167-1	VALVE RECIRCULATION	21
4063-18203	VALVE CROSS BLEED	36
4063-18204-1	VALVE COLD AIR	21
4063-18288	TRIM AIR SHUT OFF VALVE	21
4077880-960	MCDU - MULTIPURPOSE CONTROL	22
4077880-962	MCDU - MULTIPURPOSE CONTROL	22
4087262-901	TARGET CIRCULAR	52
4087271-902	PSCU - PROXIMITY SWITCH CONTROL	52
4087271-903	PSCU - PROXIMITY SWITCH CONTROL	52
4089740-961	MCDU - MULTIPURPOSE CONTROL	22
40997002	CONVERTER OZONE	21
40997003	CONVERTER OZONE	21
409GA01	ECMU - ELECTRICAL CONTACTOR	24
4131030-3	CLUSTER ASSY LUBE	49
418-00877-102	BCM - BACKUP CONTROL MODULE	27
418-00877-103	BCM - BACKUP CONTROL MODULE	27
4190-01	INVERTER STATIC	24
4207902	PUMP HYDRAULIC	29

4207903	PUMP HYDRAULIC	29
4207904	PUMP HYDRAULIC	29
4207905	PUMP HYDRAULIC	29
4207906	PUMP HYDRAULIC	29
423473-100	TRANSDUCER UNIT-POSITION	27
425-0001-7	COFFEE MAKER	25
4255317-1	TUBE	78
4255329-1	TUBE	78
4291004	MOTOR CONVERTER WIPER RH	30
4291011	MOTOR CONVERTER WIPER LH	30
4292209	LIGHT LANDING	33
4295025	ARM WIPER RH	30
4295114	LIGHT ENGINE SCAN LH	33
4295121	LIGHT ASSY ENGINE SCAN RH	33
4298117	LIGHT TAKE OFF AND TAXI	33
42D362	SWITCH DIFFERENTIAL PRESSURE	73
42D394	SWITCH DIFFERENTIAL PRESSURE	73
42D395	SWITCH DIFFERENTIAL PRESSURE	73
4305740091	BTMU BRAKE TEMPERATURE MO	32
4305790214A	COMPUTER TPIS	32
4305790214B	COMPUTER TPIS	32
4305790536A	COMPUTER TPIS	32
4305790537A	COMPUTER TPIS	32
4305890050	TRANSMITTER TPIS	32
4305990071	SENSOR TPIS	32
4313101-00-66-00	OVEN	25
4313101-00-6600	OVEN	25
4313101-01-66-00	OVEN RH	25
4313101-01-6600	OVEN RH	25
4313200-91-6600	OVEN	25

4338074	LIGHT RUNWAY TURNOFF	33
442920-1	MANIFOLD DISTRIBUTION	35
4441216-000	REDUCER-PRESSURE	35
4443	BPS - BACKUP POWER SUPPLY	27
4443-0101	BPS - BACKUP POWER SUPPLY	27
4500-4	CHILLER AIR	25
450101	TRANSDUCER UNIT POSITION	27
4510-22UG-00	BEVERAGE MAKER	25
4511-2611-00	COFFEE MAKER	25
45606111	DU - DISPLAY UNIT	31
45606112	DU - DISPLAY UNIT	31
45731-1385	HEATER SERVO FUEL	73
45731-1386	HEATER SERVO FUEL	73
457-1478	ADAPTER REFUEL OVERWING	28
4-60000H882-00	MAST ASSY DRAIN	30
4648217017	MODULE STARTER CLUTCHER	49
4648217023	MODULE STARTER CLUTCHER	49
465020-03030316	ADIRU	34
465020-03040316	ADIRU	34
466-11	SENSOR TEMPERATURE	32
47111-1201	HEAT EXCHANGER ENGINE & IDG	79
47111-1203	HEAT EXCHANGER ENGINE & IDG	79
47111-1204	HEAT EXCHANGER ENGINE & IDG	79
47147-710	ACTUATOR THS	27
47148-121	ACTUATOR UNIT PITCH TRIM	27
47148-122	ACTUATOR UNIT PITCH TRIM	27
47172-500	ACTUATOR THS	27
47172-510	ACTUATOR THS	27
47172-530	ACTUATOR THS	27
472625-1	EXTINGUISHER FIRE CARGO	26

472931-2	EXTINGUISHER FIRE CARGO	26
4E4035-2	PANEL FLOOR HEATED	25
4E4036-2	PANEL FLOOR HEATED	25
4E4037-4	PANEL FLOOR HEATED	25
4E4041-1	PANEL FLOOR HEATED	25
4E4041-2	PANEL FLOOR HEATED	25
4E4632-3	PANEL FLOOR HEATED	25
4E4632-4	PANEL FLOOR HEATED	25
4E4633-3	PANEL FLOOR HEATED	25
4E4636-2	PANEL FLOOR HEATED	25
4E4636-3	PANEL FLOOR HEATED	25
4E4636-4	PANEL FLOOR HEATED	25
4E4637-4	PANEL FLOOR HEATED	25
4E4640-5	PANEL FLOOR HEATED	25
4E4640-6	PANEL FLOOR HEATED	25
4E4641-4	PANEL FLOOR HEATED	25
4E4643-3	PANEL FLOOR HEATED	25
4E4644-2	PANEL FLOOR HEATED	25
4E4644-4	PANEL FLOOR HEATED	25
4E4735-2	PANEL FLOOR HEATED	25
4E4741-1	PANEL FLOOR HEATED	25
50150-0180	HARNESS FQI	28
50150-0277	HARNESS FQI	28
50150-0279	HARNESS FQI	28
50150-0375	HARNESS FQI	28
50150-0376	HARNESS FQI	28
50150-0409	HARNESS FQI	28
50150-0412	HARNESS FQI	28
50150-0413	HARNESS FQI	28
50G076	HEAT EXCHANGER AIR-OIL ENGINE	79

50G985	VALVE PNEUMATIC RELAY	75
50G986	SOLENOID VALVE	75
50H876	FILTER HPC BLEED AIR	75
50R295	LUBE AND SCAVENGE MAIN OIL PUMP	79
50U145	VALVE AIR HPT	75
50U683	IGN LEAD	74
5145-1-77	AUDIO SELECTOR PANEL	23
51154-04	PUMP ELECTRIC	29
51G070	VALVE PNEUMATIC RELAY	75
51G804	SOLENOID VALVE	75
51G823	HEAT EXCHANGER AIR-OIL ENGINE	79
51G859	HEAT EXCHANGER AIR-OIL ENGINE	79
51H274	TURBINE VANE - BLADE COOLING VALVE	75
51H336	VALVE OIL COOLER BYPASS	79
51H648	VALVE BLEED STAGE 9	75
51R159	PUMP OIL LUBRICATION AND SCAVENGE	71
51U711	SWITCH DIFFERENTIAL PRESSURE	71
51U736	VALVE NACELLE ANTI ICE	71
520913	CSMG - CONSTANT SPEED MOTOR	24
521B0200-01	ADAPTER ASSY PPU	27
529-70	LIGHT NAVIGATION DUAL	33
529-80	LIGHT NAVIGATION DUAL	33
52G225	PNEUMATIC SOLENOID VALVE	75
52T089	VALVE MODULATING HPT	75
52T619	VALVE MODULATING LPT	75
53-0014	ACTUATOR TWIN MOTOR	28
532A0000-02	LIMITER TORQUE	27
532A0000-03	LIMITER TORQUE	27
532A0000-04	LIMITER TORQUE	27
532B0000-01	LIMITER TORQUE	27

53C2205A0020006	CONTAINER ASSY CHEMICAL	35
53C2205F0020006	CONTAINER ASSY CHEMICAL	35
53C2206K0020006	CONTAINER ASSY CHEMICAL	35
53H057	SOLENOID COMPRESSOR HEATING & STARTER	75
5426-406-00-10	INDICATOR RESERVOIR FILLING	29
54-472	SLEEVE AXLE MLG	32
54-480	SLEEVE AXLE NLG	32
54-592	SLEEVE AXLE CLG	32
54-592-1	SLEEVE AXLE CLG	32
54-593	SLEEVE AXLE MLG	32
54-593-1	SLEEVE AXLE MLG	32
54C2205A0020006	CONTAINER ASSY CHEMICAL	35
54C2205F0020006	CONTAINER ASSY CHEMICAL	35
54C2206K0020006	CONTAINER ASSY CHEMICAL	35
5500-D1A-BF20B	PORTABLE OXYGEN CYLINDER ASSEMBLY	35
5500-J1A-BBF23A	PORTABLE OXYGEN CYLINDER ASSEMBLY	35
558CA04A31Y00	CONTACTOR THREE POLE	24
564CA01Y1	CONTACTOR THREE POLE	24
564CA04A21Y00	CONTACTOR	24
564CA04F11Y01	CONTACTOR THREE POLE	24
564CA04F21Y00	CONTACTOR THREE POLE	24
568-1-27170-002	PUMP FUEL BOOSTER	28
568-1-28300-004	PUMP FUEL BOOSTER	28
568-1-28300-100	PUMP FUEL BOOSTER	28
568-1-28300-101	PUMP FUEL BOOSTER	28
568-1-28300-103	PUMP FUEL BOOSTER	28
568-1-28301-003	CANISTER PUMP FUEL	28
568-1-28405-001	PUMP JET	28
568-1-29684-001	PLATE MOUNTING ASSY TYPE	28
56H246	VALVE START STABILITY BLEED	75

56T399	STARTER PNEUMATIC ENGINE AIR	80
57T496	VALVE AIR LPT	75
5830202-105	VALVE TURBINE	75
5830202-106	VALVE TURBINE	75
5830202-108	TURBINE CASE COOLING VALVE	75
5830202-109	TURBINE CASE COOLING VALVE	75
5830203-104	VALVE MODULATING HPT	75
5830203-105	VALVE AIR HPT	75
58H109	VALVE START STABILITY BLEED	75
58S1211074	HOSE ASSY	28
5908281	PANEL STOWAGE RAT	29
5908974-17	GCU - GENERATOR CONTROL UNIT	24
5908975-15	GPCU - GROUND POWER CONTROL	24
5911326	ACTUATOR RAM AIR TURBINE	29
5911905	ACTUATOR RAM AIR TURBINE	24
5912833	GENERATOR APU	24
5912958	ACTUATOR RAM AIR TURBINE	29
5913233	ACTUATOR RAM AIR TURBINE	29
5913234	ACTUATOR RAM AIR TURBINE	29
5915768	ACTUATOR RAM AIR TURBINE	29
5917109-1	ACTUATOR RAM AIR TURBINE	29
5917109-2	ACTUATOR RAM AIR TURBINE	29
5930638-102	VALVE AIR LPT	75
5930638-103	VALVE AIR LPT	75
5930639-102	VALVE AIR HPT	75
5930639-103	VALVE AIR HPT	75
5930639-104	VALVE AIR HPT	75
59880	INDICATOR PRESSURE DIFFERENCIAL	24
600622-00-501	JOYSTICK	25
600622-00-502	JOYSTICK	25

600623-70-602	CONTROLLER VENTILATION	21
600634-02AC	CONTROLLER VENTILATION	21
600634-03AD	CONTROLLER VENTILATION	21
600634-04AE	CONTROLLER VENTILATION	21
600634-04AF	CONTROLLER VENTILATION	21
600634-04AG	CONTROLLER VENTILATION	21
600634-04AH	CONTROLLER VENTILATION	21
61317-313	MODULE DIGITAL ELECTRONIC	27
61317-323	MODULE DIGITAL ELECTRONIC	27
62015-3	VALVE FLOAT VENT	28
6207-88-62	ANTENNA LOCALIZER	34
622-5130-820	CONTROL UNIT WEATHER RADAR	34
622-5134-064	TRAY MOUNTING	34
622-5136-801	DRIVE WEATHER RADAR ANTENNA	34
622-5137-601	ANTENNA WEATHER RADAR	34
622-8701-003	ANTENNA-RADIO ALTIMETER	34
622-8701-004	ANTENNA-RADIO ALTIMETER	34
622-8849-100	RFU - RADIO FREQUENCY UNIT	23
622-8973-104	ANTENNA TCAS	34
6259-0311	PEDAL FEEL AND TRIM UNIT	27
6259-2	PEDAL FEEL AND TRIM UNIT	27
630CC01Y1	CONTACTOR-SINGLE POLE	24
630CC04A2Y00	CONTACTOR	24
63543-253-2	DDRMI - DIGITAL DISTANCE	34
63543-253-3	DDRMI - DIGITAL DISTANCE	34
63543-253-4	DDRMI - DIGITAL DISTANCE	34
64000-111	BOOMSET	23
64050-868-1	INDICATOR-STANDBY AIRSPEED	34
640CC04A2Y00	CONTACTOR	24
64141-582-1	ALTIMETER STANDBY	34

64757-139-5	TRANSMITTER GAUGE	29
64C2205B0020006	CONTAINER ASSY CHEMICAL	35
650CC01	CONTACTOR	24
655CC01Y2	CONTACTOR	49
655CC04B2Y00	CONTACTOR	49
65C2205B0020006	CONTAINER ASSY CHEMICAL	35
6610-18168	ACTUATOR ROTARY	21
6610-18205-4	ACTUATOR ROTARY	21
6610-19878-2	ACTUATOR ROTARY	21
6610-20560-01	ACTUATOR ROTARY	21
6610-20565-01	ACTUATOR ROTARY	21
6610-20567-01	ACTUATOR ROTARY	36
668CA01	CONTACTOR THREE POLE	24
668CA04A31Y00	CONTACTOR THREE POLE	24
668CA04A41Y00	CONTACTOR THREE POLE	24
67030	VALVE SOLENOID OPERATED	52
6733A030000	VALVE FAN AIR	36
6743A010000	VALVE OVERPRESSURE	36
6763D080000	VALVE BLEED HP	36
6763D090000	VALVE BLEED HP	36
68-0005	SENSOR TEMPERATURE	28
6833B010000	VALVE FAN AIR	36
684-1024-011	TR - TRANSFORMER RECTIFIER	24
6854C020000	VALVE BLEED	36
697551001	SHAFT	27
697558001	SHAFT	27
697710001	SHAFT	27
697718001	SHAFT	27
697754001	SHAFT	27
697792001	SHAFT	27

699000AA000PC0A	FILTER HP	29
700100-3	BOX CONTROL	25
7012-17975-2	VALVE NEGATIVE RELIEF	21
7012-18088	VALVE SAFETY	21
7012-18088-03	VALVE SAFETY	21
70225A010001	FILTER ASSY	21
705CA01	CONTACTOR THREE POLE	24
706100-1	PANEL CONTROL OUTSIDE	25
707100-1	PANEL CONTROL INSIDE	25
70902-6	MANIFOLD GROUND SERVICE	29
70M000-509	REVERSER POSITION FAN LH1	78
70M000-510	REVERSER POSITION FAN RH1	78
70M000-511	REVERSER POSITION FAN LH2	78
70M000-512	REVERSER POSITION FAN RH2	78
70M000-513	REVERSER POSITION FAN LH1	78
70M000-514	REVERSER POSITION FAN RH1	78
70M000-515	REVERSER POSITION FAN LH2	78
70M000-516	REVERSER POSITION FAN RH2	78
70M001-505	FAN REVERSER ENGINE N1	78
70M001-506	FAN REVERSER ENGINE N2	78
70M001-507	FAN REVERSER ENGINE N1	78
70M001-508	FAN REVERSER ENGINE N2	78
70M009-501	FAN REVERSER KIT	78
70M100-099	FAN REVERSER LH	78
70M100-100	FAN REVERSER RH	78
70M770S019	COVER HINGE FWD LH	78
70M770S020	COVER HINGE FWD RH	78
70M983-021	LATCH FAN	78
70M983-023	LATCH FAN	78
70M985-013	LATCH	78

70N105-807	INTAKE COWL ASSY	71
70N106-801	INTAKE COWL ASSY	71
70N230-401	AIR INTAKE EXHAUST WELDED ASSY	71
70N450-401	DOOR	71
70N551-401	PANEL ACCESS P2-T2	71
70M650-079	LOCKING ACTATOR	78
710100-1	DISPLAY UNIT	25
7101-52	DETECTOR FIRE PYLON	26
71035-3	VALVE PRIORITY	29
71145-1	VALVE SOLENOID	29
7125-19900-01AA	CONTROLLER PRESSURE	21
71461-2	MANIFOLD ASSY NOSE DOOR	32
71M000-049	STRUCTURE FIXED LH	78
71M000-050	STRUCTURE FIXED RH	78
71M000-059	STRUCTURE FIXED LH	78
71M000-060	STRUCTURE FIXED RH	78
71M240-019	DOOR-PRESSURE	78
71M370-003	FITTING LINK ARM	78
71M401S003	HINGE	78
71M404-001	BRACKET	78
71M406-009	DOOR ACCESS	78
71M451-009	DOOR ACCESS LOWER	78
71M451S009	DOOR ACCESS LOWER	78
71M466S019	DOOR ACCESS	78
71M587-029	SEAL PRECOOLER DUCT	78
72029-2	FUSE HYDRAULIC UNIT	32
72029-3	FUSE HYDRAULIC UNIT	32
72061	FUSE HYDRAULIC UNIT	32
72091-27D102	FAUCET ASSY	38
72091-27-D102	FAUCET ASSY	38

72091-29D102	FAUCET ASSY	38
72091-29-D102	FAUCET ASSY	38
72095-1	MODULE ASSY CONTROL	25
72095-5	MODULE ASSY CONTROL	38
733905-1-1	PHC - PROBE HEAT COMPUTER	30
735-216-3	CBMU - CIRCUIT BREAKER MONITORING	24
735-216-4	CBMU - CIRCUIT BREAKER MONITORING	24
735-632-6	HSMU - HYDRAULIC SYSTEM MONITORING	29
735632-7	HSMU - HYDRAULIC SYSTEM MONITORING	29
7400-5	CHILLER AIR	25
740GA01Y02	ECMU - ELECTRICAL CONTACTOR	24
740GA01Y03	ECMU - ELECTRICAL CONTACTOR	24
740GA01Y04	ECMU - ELECTRICAL CONTACTOR	24
74M000-149	COWL ASSY-TRANSLATING, LH SIDE	78
74M000-150	COWL ASSY-TRANSLATING, RH SIDE	78
74M000-189	COWL ASSY-TRANSLATING, LH SIDE	78
74M000-190	COWL ASSY-TRANSLATING, RH SIDE	78
74M200-049	BLOCKER DOOR-FAN REVERSER	78
74M200-069	DOOR ASSY-BLOCKER	78
74M200-079	BLOCKER DOOR-FAN REVERSER	78
74M200S079	BLOCKER DOOR-FAN REVERSER	78
7514081-912	ANTENNA TCAS	34
7516118-24020	SDU - SATELLITE DATA UNIT	23
7516118-27020	SDU - SATELLITE DATA UNIT	23
7516118-27145	SDU - SATELLITE DATA UNIT	23
7516118-47145	SDU - SATELLITE DATA UNIT	23
7516222-901	RFU - RADIO FREQUENCY UNIT	23
7516250-20050	HPA - HIGH POWER AMPLIFIER	23
7517800-10002	TRANSPONDER ATC	34
7517800-10005	TRANSPONDER ATC	34

7517900-10020	COMPUTER TCAS	34
7520000-20140	HIGH POWER AMPLIFIER	23
752168B	IDG - INTEGRATED DRIVE GENERATOR	24
755CA01	CONTACTOR THREE POLE	24
755CA02F	CONTACTOR THREE POLE	24
758510	ADAPTER QAD	24
7588990	ELEMENT FILTER	75
7589149	FILTER HPC BLEED AIR	75
7589149-101	FILTER HPC BLEED AIR	75
7589149-102	FILTER HPC BLEED AIR	75
7591301-6	WIRE BRIGDE ASSY	78
7591301-7	WIRE BRIGDE ASSY	78
7591301-8	WIRE BRIGDE ASSY	78
7591301-9	WIRE BRIGDE ASSY	78
7592174-101	FILTER DRAIN ENGINE PUMP CASE	29
7592174-102	FILTER DRAIN ENGINE PUMP CASE	29
7592174-103	FILTER DRAIN ENGINE PUMP CASE	29
76-00	EXTINGUISHER FIRE PORTABLE	26
762947C	GEARBOX ASSY TURBINE LOWER	29
764224	PUMP OIL LUBRICATION AND SCAVENGE	79
764224A	PUMP OIL LUBRICATION AND SCAVENGE	79
764A0000-03	SENSOR TEMPERATURE	21
764B0000-01	SENSOR TEMPERATURE	21
764B0000-02	SENSOR TEMPERATURE	21
766542	GEARBOX ASSY TURBINE LOWER	29
766542A	GEARBOX ASSY TURBINE LOWER	29
766B0000-01	SENSOR PNEUMATIC OVERHEAT	21
767584K	GCU - GENERATOR CONTROL UNIT	24
767C0000-01	SENSOR PNEUMATIC TEMPERATURE	21
768084A	RAT - RAM AIR TURBINE	29

76M210-029	CASCADE SPOILER	78
76M210-039	CASCADE SPOILER	78
76M210-049	CASCADE SPOILER	78
76M220-019	CASCADE SPOILER	78
76M220-020	CASCADE SPOILER	78
76M220-029	CASCADE SPOILER	78
76M220-030	CASCADE SPOILER	78
76M220-039	CASCADE SPOILER	78
76M230-019	CASCADE SPOILER	78
76M230-020	CASCADE SPOILER	78
76M230-029	CASCADE SPOILER	78
76M230-030	CASCADE SPOILER	78
76M230-039	CASCADE SPOILER	78
76M260S049	SUPPORT	78
773A0000-01	SENSOR TEMPERATURE	21
774767-1-1	WHC-WINDOW HEAT COMPUTER	30
774860A3	PNEUMATIC STARTER	80
774860A4	PNEUMATIC STARTER	80
774860A6	PNEUMATIC STARTER	80
774860A8	PNEUMATIC STARTER	80
774860A10	PNEUMATIC STARTER	80
775538-15	STARTER CONTROL VALVE	80
777B0000-02	SELECTOR TEMPERATURE	21
77875	FEEDER TRANSMISION RFU	23
77877	FEEDER TRANSMISSION	23
77884	FEEDER INTERFACE HIGAIN	23
77893	FEEDER INTERFACE HIGAIN	23
77895	FEEDER INTERFACE HIGAIN	23
7825E	DENSITOMETER	28
785-611-2	AEVC - AVIONICS EQUIPMENT	21

785-611-4	AEVC - AVIONICS EQUIPMENT	21
785611-4	AEVC - AVIONICS EQUIPMENT	21
785-619-1	WHC - WINDOW HEAT COMPUTER	30
785-619-2	WHC - WINDOW HEAT COMPUTER	30
785-620-2	PHC - PROBE HEAT COMPUTER	30
785-620-3	PHC - PROBE HEAT COMPUTER	30
785620-3	PHC - PROBE HEAT COMPUTER	30
785840-4	BMC - BLEED MONITORING COMP	36
7A1508-003	SLIDE D1-D4	25
7A1508-053	RAFT SLIDE D3-D4 LH&RH	25
7A1508-045	SLIDE D1-D4	25
7A1508-055	RAFT SLIDE D1-D4 LH&RH	25
7A1508-123	SLIDE D1-D4	25
7A1508-125	RAFT SLIDE D1-D4 LH&RH	25
7A1509-001	SLIDE D3	25
7A1509-027	SLIDE D3	25
7A1509-037	SLIDE D3 LH&RH	25
7A1509-119	SLIDE D3	25
7A1509-121	SLIDE D3	25
7A1509-123	SLIDE D3 LH&RH	25
7A1509-125	SLIDE D3 LH&RH	25
7A1510-055	SLIDE D3	25
7A1510-056	SLIDE D3	25
7A1510-125	SLIDE D3	25
7A1510-126	SLIDE D3	25
7A1539-045	RAFT SLIDE D2	25
7A1539-046	RAFT SLIDE D2	25
7A1539-053	RAFT SLIDE D2	25
7A1539-055	RAFT SLIDE D2 LH	25
7A1539-056	RAFT SLIDE D2 RH	25

7A1539-117	RAFT SLIDE D2 LH	25
7A1539-118	RAFT SLIDE D2 RH	25
7A1539-123	RAFT SLIDE D2	25
7A1539-124	RAFT SLIDE D2	25
7A1539-125	RAFT SLIDE D2 LH	25
7A1539-126	RAFT SLIDE D2 RH	25
801A3100-01	JOINT UNIVERSAL	27
801A3300-01	JOINT UNIVERSAL	27
8054-19-0000	OVEN LH	25
81-00000	RGU - RATE GYRO UNIT	27
81-00001	RGU - RATE GYRO UNIT	27
811050-1	STARTER PNEUMATIC ENGINE AIR	80
811050-2	STARTER PNEUMATIC ENGINE AIR	80
811050-3	STARTER PNEUMATIC ENGINE AIR	80
811050-4	STARTER PNEUMATIC ENGINE AIR	80
822-0297-020	RECEIVER VOR MARKER	34
822-0299-020	RECEIVER ADF	34
822-0329-020	INTERROGATOR DME	34
822-0330-020	TRANSCEIVER HF	23
822-0334-020	TRANSCEIVER RADIO ALTIMETER	34
822-0953-001	HPA - HIGH POWER AMPLIFIER	23
822-0953-002	HPA - HIGH POWER AMPLIFIER.	23
822-0987-003	COUPLER HF ANTENNA DIGITAL	23
822-0990-003	TRANSCEIVER HF	23
822-1152-131	MMR - MULTI MODE RECEIVER	34
822-1250-020	TRANSCEIVER VDR	23
822-1287-120	TRANSCEIVER VHF	23
822-1287-121	TRANSCEIVER VHF	23
822-1293-332	COMPUTER TCAS	34
822-1330-001	ANTENNA GPS ACTIVE	34

822-1338-021	TRANSPONDER ATC	34
822-1637-001	SIU - SERVER INTERFACE UNIT	46
822-1637-103	SIU - SERVER INTERFACE UNIT	46
822-1710-203	TRANSCEIVER WEATHER RADAR	34
822-1710-204	TRANSCEIVER WEATHER RADAR	34
822-1710-213	TRANSCEIVER WEATHER RADAR	34
822-1710-214	TRANSCEIVER WEATHER RADAR	34
822-1821-430	MMR - MULTI MODE RECEIVER	34
822-2033-001	ANTENNA GPS ACTIVE	34
822-2169-201	ANSU - AIRCRAFT NETWORK	46
822-2325-020	INTERROGATOR DME	34
822830-14-034	CONTROL ELEC ENGINE	73
833-2102	SHAFT DRIVE	27
833A2100-01	SHAFT ASSY SLAT DRIVE	27
833A2700-01	SHAFT ASSY CONNECTION	27
833A2800-01	SHAFT ASSY CONNECTION	27
8378M12	COMPRESSOR AIR	38
84333-00-0304	SFCC - SLAT FLAP CONTROL	27
84333-00-0305	SFCC - SLAT FLAP CONTROL	27
84354335	RCCB - REMOTE CONTROL CIRCUIT BREAKER	27
84354350	RCCB - REMOTE CONTROL CIRCUIT BREAKER	27
8-552-01	SWITCH PROXIMITY	32
86006-11	LATCH	25
86007-30	LATCH	25
86050-11	LATCH DOUBLE	25
86065-10	SPLITTER	25
86070-40	LATCH DOUBLE	25
86500-109	VALVE SHUTOFF WATER	38
86500-109AMDTB	VALVE SHUTOFF WATER	38
86500-109AMDTC	VALVE SHUTOFF WATER	38

86600-103	VALVE FLUSH	38
86600-103REVL	VALVE FLUSH ROTARY	38
8-678-03	SENSOR PROXIMITY SWITCH	52
8-695-01	SENSOR PROXIMITY CIRCULAR	52
87232329V03	ADM - AIR DATA MODULE	34
87232329V07	ADM - AIR DATA MODULE	34
87292337V04M02	FCDC - FLIGHT CONTROL DATA	27
87292337V04M04	FCDC - FLIGHT CONTROL DATA	27
87292337V04M05	FCDC - FLIGHT CONTROL DATA	27
87292337W01M03	FCDC - FLIGHT CONTROL DATA	27
87292337W01M04	FCDC - FLIGHT CONTROL DATA	27
87292337W01M05	FCDC - FLIGHT CONTROL DATA	27
8-753-03	TARGET COMBINED TRACK	27
887677	SOLENOID	29
89-01-07000	HANDSET COCKPIT	23
89-01-07032	HANDSET CABIN	23
89-01-07042	HANDSET CABIN	23
89-01-07350	HANDSET	23
892480	FIRE EXTINGUISHER	26
89794077	CYLINDER ASSY OXYGEN	35
898052	FIRE EXTINGUISHER	26
899-0850-004	RMP - RADIO MANAGEMENT PANE	23
8-992-01	SENSOR PROXIMITY RECTANGULARE	52
8-995-01	CONTROL UNIT PROXIMITY SWITCH	52
8-995-02	CONTROL UNIT PROXIMITY SWITCH	52
8ES004692-10	POWER UNIT	31
8ES004692-20	POWER UNIT	33
8ES005304-00	PSU - POWER SUPPLY UNIT	33
8ES005309-00	PSU - POWER SUPPLY UNIT	33
8ES403703-02	TRANSFORMER REAR NAVIGATION	33

8ES455012-00	PSU - POWER SUPPLY UNIT	33
8ES455012-06	PSU - POWER SUPPLY UNIT	33
8ES455438-07	PSU - POWER SUPPLY UNIT	33
8ES455440-06	PSU - POWER SUPPLY UNIT	33
9000000-11414	COMPUTER TCAS	34
900974-03	DETECTION SYSTEM FIRE LH	78
900974-04	DETECTION SYSTEM FIRE RH	78
9028A0005-01	PPU - POSITION PICK-OFF UNIT	27
9047A0019-01	SERVO VALVE	27
9047A0027-03	SERVO VALVE	27
9070C0002-01	SENSOR AIRFLOW	21
9104A0005-01	SENSOR PRESSURE	21
9105A0005-01	SENSOR TEMPERATURE	21
9105A0005-02	SENSOR TEMPERATURE	21
9106A0003-01	SENSOR PRESSURE	21
9106A0003-02	SENSOR PRESSURE	21
9107A0009-02	SOLENOID VALVE	27
918A1000-01	BRAKE PRESSURE OFF	27
918B0000-01	PCU - POWER CONTROL UNIT	27
91E558-01	PIN UPPER PIVOT DOOR	78
91E738-02	ROLLER UPPER PIVOT DOOR	78
91F235-03	T/R TERTIARY LOCK	78
920582	CSMG - CONSTANT SPEED MOTOR	24
920A0000-05	BLOCK VALVE	27
92153A030000	GRU ELECTRONIC CTRL BOX	27
921D0000-01	GEARBOX TEE	27
92236A010000	TRANSDUCER	36
92237B010000	TRANSDUCER	36
92239B010000	SENSOR TEMPERATURE	36
924C0000-01	GEARBOX BEVEL	27

926C0000-01	ACTUATOR ROTARY	27
928005	GCU - GENERATOR CONTROL UNIT	24
930-2000-001	TRANSCEIVER WXR	34
930-3001-001	DRIVE WEATHER RADAR ANTENNA	34
930-4301-001	ANTENNA WEATHER RADAR	34
930-7002-001	MOUNTING TRAY	34
933252	MOTOR HYDRAULIC	27
93572-06	BRACKET APU REAR	49
93572-07	BRACKET SUPPORT	49
93572-08	BRACKET SUPPORT	49
937A2300-01	SHAFT ASSY	27
937A6000-01	BEARING	27
937A6100-01	BEARING	27
937A6200-01	BEARING	27
937B1000-01	SHAFT ASSY TORQUE	27
937B1100-01	SHAFT ASSY COMPLIANT	27
937B1300-01	SHAFT ASSY TORQUE	27
937B1400-01	SHAFT ASSY TORQUE	27
937C1200-01	SHAFT ASSY COMPLIANT	27
937C1700-01	SHAFT ASSY TORQUE N8	27
937C1900-01	SHAFT ASSY TORQUE N11	27
937C2400-01	SHAFT ASSY TORQUE N26	27
937C2600-01	SHAFT ASSY TORQUE N30	27
937C2700-01	SHAFT ASSY TORQUE N32	27
937C2800-01	SHAFT ASSY TORQUE N36	27
937C2900-01	SHAFT ASSY TORQUE N38	27
937C3600-01	SHAFT ASSY TORQUE N58	27
937C3700-01	SHAFT ASSY TORQUE N60	27
937D1500-01	SHAFT ASSY TORQUE N5	27
937D1700-01	SHAFT ASSY TORQUE N8	27

937D1800-01	SHAFT ASSY TORQUE N10	27
937D1900-01	SHAFT ASSY TORQUE N11	27
937D2000-01	SHAFT ASSY TORQUE N12	27
937D2100-02	SHAFT ASSY TORQUE N14	27
937D2400-01	SHAFT ASSY TORQUE N26	27
937D2500-02	SHAFT ASSY TORQUE N28	27
937D2600-01	SHAFT ASSY TORQUE N30	27
937D2700-01	SHAFT ASSY TORQUE N32	27
937D2800-01	SHAFT ASSY TORQUE N36	27
937D2900-01	SHAFT ASSY TORQUE N38	27
937D3400-01	SHAFT ASSY TORQUE N50	27
937D3500-01	SHAFT ASSY TORQUE N54	27
937D3600-01	SHAFT ASSY TORQUE N58	27
937D3700-01	SHAFT ASSY TORQUE N60	27
937D3800-01	SHAFT ASSY TORQUE N52	27
937E1500-01	SHAFT ASSY TORQUE N5	27
937E1700-01	SHAFT ASSY TORQUE N8	27
937E1800-01	SHAFT ASSY TORQUE N10	27
937E1900-01	SHAFT ASSY TORQUE N11	27
937E2000-01	SHAFT ASSY TORQUE N12	27
937E2100-01	SHAFT ASSY-TORQUE N14	27
937E2400-01	SHAFT ASSY TORQUE N26	27
937E2500-01	SHAFT ASSY TORQUE N28	27
937E2600-01	SHAFT ASSY TORQUE N30	27
937E2700-01	SHAFT ASSY TORQUE N32	27
937E2800-01	SHAFT ASSY TORQUE N36	27
937E2900-01	SHAFT ASSY TORQUE N38	27
937E3300-01	SHAFT ASSY TORQUE N48	27
937E3400-01	SHAFT ASSY TORQUE N50	27
937E3500-01	SHAFT ASSY TORQUE N54	27

937E3600-01	SHAFT ASSY TORQUE N58	27
937E3700-01	SHAFT ASSY TORQUE N60	27
937E3800-01	SHAFT ASSY TORQUE	27
93N6035	PANEL CONTROL	25
940-0351-001	COMPUTER TCAS	34
940-0351-005	COMPUTER TCAS	34
94-1-1100-01	ACTUATOR EMERGENCY RAM	21
9508175	VALVE FLOAT VENT	28
952C0200-01	SHAFT ASSY TORQUE N47	27
952D0200-01	SHAFT ASSY TORQUE N47	27
952E0200-01	SHAFT ASSY TORQUE N47	27
95394-04	ISOLATOR APU FWD	49
95394-05	ISOLATOR APU FWD	49
95394-06	ISOLATOR APU REAR	49
953B0000-02	PCU - POWER CONTROL UNIT	27
954C0000-01	ACTUATOR ROTARY	27
957B0000-01	VALVE TEMPERATURE CONTROL	21
958A0000-02	VALVE BYPASS	21
958A0000-03	VALVE BYPASS	21
9599-607-12352	ANTENNA RADIO ALTIMETER	34
9599-607-19502	TRANSCEIVER RADIO ALTIMET	34
9599-607-19504	TRANSCEIVER RADIO ALTIMET	34
959A0000-01	INJECTOR WATER	21
96154570512X	DMC - DISPLAY MANAGEMENT CO	31
961A0000-01	VALVE CHECK	21
962A0000-06	VALVE TRIM AIR PRESSURE	21
962A0000-07	VALVE TRIM AIR PRESSURE	21
9630100-1221	VALVE ASSY DRAIN	38
9630100-1311	MANIFOLD	38
9630100-1501	VALVE FLOAT	38

9630602-2001	CONDITIONER WATER	38
9633501-3001	CONTROL ASSY CABLE	38
9633501-4001	CONTROL ASSY CABLE	38
9633502-0001	CONTROL ASSY CABLE	38
9633502-1001	LEVER UNIT SERVICE PANEL	38
9633502-2001	CONTROL ASSY CABLE	38
9633502-3001	CONTROL ASSY CABLE	38
964-0452-012	TRANSCEIVER HF	23
964-0452-052	TRANSCEIVER HF	23
964-0453-001	COUPLER HF ANTENNA	23
964A0000-03	VALVE FLOW CONTROL	21
964A0000-04	VALVE FLOW CONTROL	21
964A0000-05	VALVE FLOW CONTROL	21
964A0000-06	VALVE FLOW CONTROL	21
964F0000-01	VALVE FLOW CONTROL	21
964F0000-02	VALVE FLOW CONTROL	21
965-1676-001	GPWC - GROUND PROXIMITY WARNING	34
965-1676-002	GPWC - GROUND PROXIMITY WARNING	34
965-1676-003	GPWC - GROUND PROXIMITY WARNING	34
965A0000-02	ACM - AIR CYCLE MACHINE	21
966A0000-01	EXCHANGER HEAT PRIMARY	21
966A0000-02	EXCHANGER HEAT PRIMARY	21
966A0000-03	EXCHANGER HEAT PRIMARY	21
967-0514-002	DMU - DATA MANAGEMENT UNIT	31
967A0000-02	EXCHANGER HEAT MAIN	21
967A0000-03	EXCHANGER HEATMAIN	21
968214-6	VALVE ASSY PRESSURE RELIEF	49
968A0000-03	REHEATER	21
969A0000-02	CONDENSER	21
970A0000-02	EXTRACTOR WATER	21

970A0000-03	EXTRACTOR WATER	21
971844	PUMP-HYDRAULIC	29
971A0000-02	DUCT SPLIT	21
971A0000-03	DUCT SPLIT	21
971A0000-04	DUCT SPLIT	21
972A0000-03	VALVE ANTI ICING	21
972630	PUMP HYDRAULIC	29
974540	PUMP ELECTRIC	29
974800	ENG DRIVEN PUMP	29
974947	PUMP HYDRAULIC	29
974976	PUMP HYDRAULIC	29
975A0000-02	ACTUATOR RAM AIR INLET	21
975A0000-03	ACTUATOR RAM AIR INLET	21
976A0000-02	ACTUATOR RAM AIR OUTLET	21
977C0000-04	CONTROLLER PACK TEMPERATURE	21
977C0000-05	CONTROLLER PACK TEMPERATURE	21
977C0000-06	CONTROLLER PACK TEMPERATURE	21
977C0000-07	CONTROLLER PACK TEMPERATURE	21
978B0000-02	CONTROLLER ZONE TEMPERATURE	21
978B0000-03	CONTROLLER ZONE TEMPERATURE	21
978C0000-04	CONTROLLER ZONE TEMPERATURE	21
978C0000-05	CONTROLLER ZONE TEMPERATURE	21
978C0000-06	CONTROLLER ZONE TEMPERATURE	21
978C0000-07	CONTROLLER ZONE TEMPERATURE	21
978C0000-08	CONTROLLER ZONE TEMPERATURE	21
979786-2	VALVE SHUTOFF AND BLEED	49
979786-4	VALVE SHUTOFF AND BLEED	49
979786-5	VALVE SHUTOFF AND BLEED	49
980-4700-042	SSFDR - SOLID STATE FLIGHT	31
980-6022-001	CVR - COCKPIT VOICE RECORDER	23

980-6032-020	CVR - COCKPIT VOICE RECORDER	23
980B0000-02	VALVE CHECK DOWNSTREAM	21
982A0000-01	VALVE CHECK TRIM AIR	21
983A0000-02	ACM - AIR CYCLE MACHINE	21
983A0000-03	ACM - AIR CYCLE MACHINE	21
9843169L	VALVE CHECK	28
98D34103007000	AOA PROBE TESTER	34
9910857-202	DUCT TELESCOPIC ANTI ICE	30
9913252-101	DUCT TELESCOPIC ANTI ICE	30
A05B00	ACTUATOR-ELECTRICAL	38
A06000	ACTUATOR ASSY	28
A06L00	ACTUATOR ASSY	29
A08000	ACTUATOR ASSY	28
A200300	CONTROL UNIT ANNUNCIATOR	33
A25312-1	VALVE THROTTLE	32
A25313002	VALVE BRAKE SELECTOR	32
A25313002-1	VALVE BRAKE SELECTOR	32
A25313002-2	VALVE BRAKE SELECTOR	32
A25313003	VALVE BRAKE SELECTOR	32
A25313003-1	VALVE BRAKE SELECTOR	32
A25313003-2	VALVE BRAKE SELECTOR	32
A25315020-1	VALVE BRAKE PARK HYDRAULIC	32
A25316020	VALVE DUAL SHUTTLE	32
A25317-1	VALVE SAFETY	29
A25434021-1	VALVE EMERGENCY BRAKE	32
A25434021-2	VALVE EMERGENCY BRAKE	32
A25461020-2	SELECTOR BRAKE AUTOMATIC	32
A2727086500600	SPRING ROD RUDDER SERVO	27
A2727086501000	SPRING ROD RUDDER SERVO	27
A2577285000600	GUIDE	25

A3348-049	SUPPORT RETECTABLE	78
A3348-059	SUPPORT RETECTABLE	78
A3445-10	STRUT ASSEMBLY	71
A3403220100000	RADOME ASSY	53
A400140-1	LATCH	50
A64982-004	ACTUATOR IGV	49
A64982-3	ACTUATOR IGV	49
A64982-4	ACTUATOR IGV	49
A9232024200010	RADOME ASSY	53
A9232024200011	RADOME ASSY	53
A9232024200012	RADOME ASSY	53
A9232060600500	RADOME ASSY	53
A9232060600600	RADOME ASSY	53
A9232060600700	RADOME ASSY	53
AC40-0227230	NET DOOR	25
AC40-0227243	NET CORNER	25
AC40-0227253	NET DIVIDER	25
AC55-0227310	SCREEN	25
ACP2788AE01	ACP - AUDIO CONTROL PANEL	23
ACP2788AF01	ACP - AUDIO CONTROL PANEL	23
ACU3855-01	COOLING UNIT AIR	25
ACU3855-02	AIR COOLER UNIT	21
AE1011406P0636	HOSE ASSY	29
AE1011407N0284	HOSE ASSY	29
AE1502U02	MOTOR ASSY BRAKE FAN	32
AE86195G	VALVE ASSY FILL	29
AE86773K	COUPLING HALF SELF SEALING	29
AE87671P	COUPLING HALF SELF SEALING	29
AE96996P	COUPLING HALF SELF SEALING	29
AE96997M	COUPLING HALF SELF SEALING	29

AM42905709-A01	PRINTER	23
AMU4031LA120102	AMU - AUDIO MANAGEMENT UNIT	23
AMU4031LA130103	AMU - AUDIO MANAGEMENT UNIT	23
AMU4031LA140204	AMU - AUDIO MANAGEMENT UNIT	23
APE5100-1	CLOCK	31
AR02404	ACTUATOR ROTARY	32
AR4710-3	PAD KEY	52
AR4753-6	BOLTING SYSTEM DOOR	52
AR4754-2	LATCH DOOR CENTER	52
AR4756-1	STRIKE ELECTRIC CTR	52
AR4756-3	STRIKE ELECTRIC CTR	52
AR4757-1	CONTROL COCKPIT SYSTEM	52
AR4862-3	DECOMPRESSION SYSTEM	25
AR4922-1	PAD KEY	52
AR4922-3	PAD KEY	52
AR9013-5W1D102	FAUCET WATER	38
AR9013-5W1D605	FAUCET WATER	38
AR9013-5W2D102	FAUCET WATER	38
AR9013-5W3D102	FAUCET WATER	38
AR9013-5W4D102	FAUCET WATER	38
AT0516A02	TURBOFAN	21
AT0516AA1	TURBOFAN	21
AW2044AB02	GAGE NITROGEN PRESSURE	29
B11A00	VALVE FUEL ISOLATION	28
B12000	VALVE SHUTOFF FUEL FIRE	28
B33025-004	SERVOVALVE ELECTRO HYDRAULIC	27
B33025-005	SERVOVALVE ELECTRO HYDRAULIC	27
B33026-004	SERVOVALVE ELECTRO HYDRAULIC	27
B33026-005	SERVOVALVE ELECTRO HYDRAULIC	27
B43350-1	REGULATOR OXYGEN	35

B492AAM0410	FCSC - FLIGHT CONTROL	27
B492AAM0411	FCSC - FLIGHT CONTROL	27
B494AAM0615	COMPUTER CONTROL AND MONITORING	28
B494AAM0616	COMPUTER CONTROL AND MONITORING	28
B494AAM0617	COMPUTER CONTROL AND MONITORING	28
B494AAM0618	COMPUTER CONTROL AND MONITORING	28
B97-51-601	VALVE TRIM TANK ISOLATION	28
B97H38-605	VALVE FUEL TANK INLET	28
B97H51-604	VALVE TRANSFER FUEL	28
B97H51-605	VALVE FUEL TANK INLET	28
B97H51-606	VALVE TRANSFER FUEL	28
B97H63-605	VALVE FUEL TANK INLET	28
B97H63-615	VALVE BALL WING	28
B97H63-628	VALVE FUEL TANK INLET	28
B97P38-602	VALVE TRANSFER INTERTANK	28
BA04105	GENERATOR APU	24
C0834F100	PLATE INTEGRALLY LIGHTED	33
C12349AC02	PRINTER	23
C12349AD03	PRINTER	23
C12351AA	ANTENNA ADF	34
C12402AA02	CONTROL UNIT ATC-TCAS	34
C12404AB02	CONTROL UNIT ATC-TCAS	34
C12848AA01	RMP - RADIO MANAGEMENT PANEL	23
C12848CA01	RMP - RADIO MANAGEMENT PANEL	23
C12848CB01	RMP - RADIO MANAGEMENT PANEL	23
C12848DB01	RMP - RADIO MANAGEMENT PANEL	23
C12848EA01	RMP - RADIO MANAGEMENT PANEL	23
C12849AA01	FCU - FLIGHT CONTROL UNIT	22
C12849AB02	FCU - FLIGHT CONTROL UNIT	22
C12849AB03	FCU - FLIGHT CONTROL UNIT	22

C12849AB04	FCU - FLIGHT CONTROL UNIT	22
C12849DA01	FCU - FLIGHT CONTROL UNIT	22
C12858CA01	FMGEC - FLEET MANAGEMENT	22
C12858CA02	FMGEC - FLEET MANAGEMENT	22
C13039CA01	FMGEC - FLEET MANAGEMENT	22
C13164HA01	FMGEC - FLEET MANAGEMENT	22
C13164HA02	FMGEC - FLEET MANAGEMENT	22
C13200HA01	FMGEC - FLEET MANAGEMENT	22
C13226HA07	FMGEC - FLEET MANAGEMENT	22
C145531-3	VALVE ANTI ICING	30
C145531-5	VALVE ANTI ICING	30
C143620-2	VALVE CHECK VALVE STAGE 8	36
C143620-3	VALVE CHECK VALVE STAGE 8	36
C145531-3	VALVE NACELLE ANTI ICE	30
C148275-1	VALVE NACELLE COOLING	75
C16221VA01	INDICATOR	34
C16221WB01	INDICATOR	34
C16235AA	INDICATOR BRAKE PRESSURE	32
C18124AA	RATE GYRO UNIT	27
C18171AA	ACCELEROMETER UNIT	27
C19266EA01	MCDU-MULTIPURPOSE CONTROL	22
C19298AF05	DU-DISPLAY UNIT	31
C19366AF05	DU-DISPLAY UNIT	31
C19755BA01	DU-DISPLAY UNIT	31
C20105100	TACHOMETER	32
C20105100-1	TACHOMETER	32
C20215000	TRANSMITTER BRAKE PEDAL	32
C20288000-2	ACCUMALATOR NORMAL BRAKE	32
C2029339A9A9A	BSCU - BRAKING AND STEERING	32
C2029339B9B9B	BSCU - BRAKING AND STEERING	32

C20288000-1	ACCUMULATOR BRAKE	32
C20288000-2	ACCUMULATOR BRAKE	32
C2029339C9C9C	BSCU - BRAKING AND STEERING	32
C2029339D9D9D	BSCU - BRAKING AND STEERING	32
C20327000	VALVE SERVO	32
C20327000-001	VALVE SERVO	32
C2033629D	BSCU - OBRM 1 9D	32
C2033829D	BSCU - OBRM 3 9D	32
C20374000-2	VALVE-SERVO.BRAKE	32
C24592020	CYLINDER MASTER	32
C24592020-1	CYLINDER MASTER	32
C24703002-1	LIMITER PARKING PRESSURE	32
C24703002-2	LIMITER PARKING PRESSURE	32
C24757020	VALVE SAFETY	32
C24777020-3	MANIFOLD NORMAL BRAKE	32
C24782000-3	VALVE SOLENOID	32
C24819000-3	MANIFOLD PARKING BRAKE	32
C24819000-4	MANIFOLD PARKING BRAKE	32
C24830000-3	UPLOCK DOOR	32
C24830000-4	UPLOCK DOOR NLG	32
C24831300-1	UPLOCK MLG	32
C24833100-4	UPLOCK DOOR	32
C24834000-6	UPLOCK NLG	32
C24856000-3	BLOCK ELECTRO HYDRAULIC	32
C24856000-4	BLOCK ELECTRO HYDRAULIC	32
C24856000-5	BLOCK ELECTRO HYDRAULIC	32
C24856000-6	BLOCK ELECTRO HYDRAULIC	32
C24856000-7	BLOCK ELECTRO HYDRAULIC	32
C24856000-9	BLOCK ELECTRO HYDRAULIC	32
C24856000-11	BLOCK ELECTRO HYDRAULIC	32

C24856001-1	BLOCK ELECTRO HYDRAULIC	32
C24856001-2	BLOCK ELECTRO HYDRAULIC	32
C24856001-3	BLOCK ELECTRO HYDRAULIC	32
C24856001-4	BLOCK ELECTRO HYDRAULIC	32
C24856001-5	BLOCK ELECTRO HYDRAULIC	32
C24856001-6	BLOCK ELECTRO HYDRAULIC	32
C24856001-7	BLOCK ELECTRO HYDRAULIC	32
C24856001-9	BLOCK ELECTRO HYDRAULIC	32
C24857000-1	VALVE SWIVEL SELECTOR	32
C24858000	BOX SENSOR	32
C24859000	GEARBOX NOSE WHEEL STEERING	32
C24879020-3	MANIFOLD BRAKE	32
C24880020-3	MANIFOLD BRAKE	32
C24891020	RESERVOIR HYDRAULIC	32
C24891020-2	RESERVOIR HYDRAULIC	32
C24960000-1	VALVE SAFETY	29
C24984000	VALVE SHUTOFF	32
C31007AA01	PRINTER	45
C38657-002	SERVOCONTROL OUTBRD AILERON	27
C38661-002	SERVOCONTROL INBRD AILERON	27
C4FL0593C02	PLATE INTEGRALLY LIGHTED	33
C4FL0675C02	PLATE INTEGRALLY LIGHTED	33
C51LM0030	SELECTOR VALVE	29
C93L19-201	CANISTER PUMPAFT	28
CAR101	VALVE CHECK	29
CAR301	VALVE CHECK	29
CAR370-1	VALVE CHECK	29
CAR70	VALVE CHECK	29
CB03903-01	GCU - GENERATOR CONTROL UNIT	24
CB03903-01-17	GGPCU - GENERATOR AND GROUND	24

CD00901-03	GPCU - GROUND POWER CONTROL UNIT	24
CD00902-01	GPCU - GROUND POWER CONTROL	24
CE101220-0005	ACTUATOR DOOR CARGO	52
CE101220-0007	ACTUATOR DOOR CARGO	52
CE101230-0003	VALVE CONTROL	52
CE101230-0005	VALVE CONTROL	52
CE101232C0003	SOLENOID ASSY	52
CE1909AA1	FAN EXTRACTION	21
CM9190-00	MODULE CODING	26
D05A00	VALVE DRAIN	38
D05C00	VALVE FILL AND DRAIN	38
D23119550	BOX ELECTRICAL NLG	32
D23297000-1	LINK LOCK NLG	32
D23298000	ACTUATOR LOCKSTAY	32
D23352000-1	ACTUATOR RETRACTION NLG	32
D23352000-2	ACTUATOR RETRACTION NLG	32
D23352000-3	ACTUATOR RETRACTION NLG	32
D23445000	FITTING ASSY FRONT TOWING	32
D23445000-1	FITTING ASSY FRONT TOWING	32
D23446100	LOOM UPPER ELECTRICAL	32
D23448000	LOOM LOWER ELECTRICAL	32
D23449000	ACTUATOR STEERING	32
D23450000	VALVE CHANGE OVER	32
D23450000A	VALVE CHANGE OVER	32
D23585000	BOX ELECTRICAL TOWBARLESS	32
D23809000	BOX ELECTRICAL NLG	32
D25AB2431	VALVE RELIEF	29
D26AB1042	VALVE CUT OUT	32
D26AB1044	VALVE CUT OUT	32
D26AB1061	VALVE VENT FREE FALL	32

D31AB4414	SELECTOR LANDING GEAR	32
D31AB4415	SELECTOR LANDING GEAR	32
D31AB4431	VALVE SAFETY MLG	32
D31AB4433	VALVE SAFETY MLG	32
D90ST0118-100	SERVOVALVE	27
D90ST4209-100	MODULE DIGITAL ELECTRONIC	27
D97C00-609	ACTUATOR SINGLE	28
D97C00-624	ACTUATOR SINGLE	28
D97C00-654	ACTUATOR SINGLE	28
D97C00-664	ACTUATOR SINGLE	28
D97C00-682	ACTUATOR SINGLE	28
DAP00076-01-51	WHEEL ASSY AND TIRE	32
DPE110	PORTABLE TESTER	35
DR3174	MONITOR ATTITUDE	28
DR31740000GA	MONITOR ATTITUDE	28
DV8902AA1	DETECTOR COOL EFFECT	21
DVA9466-00	DRAIN VALVE ACTUATION	38
DVE90-06	VALVE SOLENOID	35
DVE90-07	VALVE SOLENOID	35
DVE91	VALVE SOLENOID	35
E03A00	VALVE ASSY FIRE SHUTOFF	29
E21350000	TACHOMETER DRIVE SHAFT	32
E28180-10	PBE	35
E28180-20-0001	PBE	35
E28180-20-0006	PBE - PROTECTIVE BREATHING	35
E61751-00-0001	REDUCER PRESSURE	26
E62908-00	TRANSDUCER TEMPERATURE	35
EEC2000-07BV	EEC - ELEC ENG CTR T700	73
EEC2000-07BW	EEC - ELEC ENG CTR T700	73
EEC2000-07BX	EEC - ELEC ENG CTR T700	73

EEC2010-02BX	EEC - ELEC ENG CTR T700	73
F05A00	SWITCH DIFFERENTIAL PRESSURE	21
F27310012000AP	CONTROLLER ASSY SIDE STIC	27
F33110345A00	PLATE INTEGRALLY LIGHTED	33
F2727104900000	ROD SPRING RUDDER	27
F2727156000000	ROD	27
F2727156000200	ROD	27
F53132010000	RADOME ASSY	53
F53132110000	RADOME ASSY	53
F53132210000	RADOME ASSY	53
F5735349000139Z	WINGLET ASSY RH	57
F5746219800200	SLAT ASSY N1 LH	57
F5746219800500	SLAT ASSY N1 RH	57
F5746219800600	SLAT ASSY N1 LH	57
F5746239800200Z	SLAT ASSY N3 LH	57
F5746239800300Z	SLAT ASSY N3 RH	57
F5746347800000Z	SLAT ASSY N4 LH	27
F5761050003100	AILERON OUTER EQUIPPED RH	57
F5761050702000	OUTER AILERON ASSY LH	27
F5761050702100	OUTER AILERON ASSY RH	27
FA00512A	FILTER ASSY	29
FA03090A	FILTER RESERVOIR	29
FA04804A	FILTER ASSY	29
FA00914D	FILTER FUEL DOWN STREAM	73
FCM9130-01	MODULE FLUSH CONTROL	25
FE127-02-003	ACTUATOR DOOR PASSENGER	52
FE256-000	ACTUATOR DOOR PASSENGER	52
FE256-001	ACTUATOR DOOR PASSENGER	52
FE276-000	ACTUATOR DOOR EMERGENCY	52
FE276-001	ACTUATOR DOOR EMERGENCY	52

FE276-002	ACTUATOR DOOR EMERGENCY	52
FE412000104	SSU - SIDE STICK UNIT CAPTAIN	27
FE412000105	SSU - SIDE STICK UNIT FIST OFFICER	27
FE412000106	SSU - SIDE STICK UNIT CAPTAIN	27
FE412000107	SSU - SIDE STICK UNIT FIST OFFICER	27
FH1033	WAVE GUIDE ASSY	34
FRH010041	ACTUATOR TWIN MOTOR	28
FRH100002A	SWITCH PRESSURE	28
FRH100028A	SWITCH PRESSURE	28
FRH210008M	VALVE RESTRICTOR	28
FRH230003C	VALVE PRESSURE REDUCER	38
FRH280002	VALVE AIR RELEASE	28
FRH340002B	VALVE DRAIN WATER	28
FRH340004	VALVE DRAIN WATER	28
FRH340005	VALVE DRAIN WATER	28
FRH530017C	VALVE GAS CHARGING	28
FV9930-00	VALVE ASSY FLUSH	38
FV9930-01	VALVE ASSY FLUSH	38
G2557674000000	PANEL ASSY CEILING	25
G2557674200000	PANEL ASSY CEILING	25
G2557674600000	PANEL ASSY CEILING	25
G2557674800000	PANEL ASSY CEILING	25
G2557675000800	PANEL ASSY CEILING	25
G2557676200000	AFT PANEL ASSY SIDEWALL	25
G2557676600000	AFT PANEL ASSY SIDEWALL	25
G2557676800000	AFT PANEL ASSY SIDEWALL	25
G2557683800000	PANEL ASSY CEILING	25
G2557692400000	PANEL ASSY SIDEWALL	25
G2557692600000	AFT PANEL ASSY SIDEWALL	25
G2557694800200	AFT PANEL ASSY SIDEWALL	25

G2557694801000	AFT PANEL ASSY SIDEWALL	25
G2557695200000	AFT PANEL ASSY SIDEWALL	25
G2557695400000	AFT PANEL ASSY SIDEWALL	25
G2557715000000	PANEL ASSY CEILING	25
G2557715200000	PANEL ASSY CEILING	25
G2557717000000	PANEL ASSY SIDEWALL	25
G2557720200000	AFT PANEL ASSY SIDEWALL	25
G2557720400000	AFT PANEL ASSY SIDEWALL	25
G2557722200000	PANEL ASSY CEILING	25
G2557722500000	PANEL ASSY CEILING	25
G2557722600000	PANEL ASSY CEILING	25
G2557734200000	PANEL ASSY CEILING	25
G2557734800000	PANEL ASSY CEILING	25
G540DA51-01	VALVE WASTE DRAIN	38
G540DA72	SEPARATOR WASTE	38
G540DA74	TRANSMITTER LIQUID LEVEL	38
GB2000AA0	VALVE CHECK	21
GMC1102-02	SMOKE DETECTOR	26
GMC1103-02	SMOKE DETECTOR	26
GPA1102-00	SMOKE DETECTOR	26
GPA1103-00	SMOKE DETECTOR	26
GWD9180-00	BIN WASTE DISPOSAL GALLEY	38
GWD9180-01	BIN WASTE DISPOSAL GALLEY	38
GWD9180-10	BIN WASTE DISPOSAL GALLEY	38
H2883-9	LATCH	78
H2885-1	HOOK LATCH FAN COWL	78
H2885-3	HOOK LATCH FAN COWL	78
H2885-5	LATCH ASSEMBLY	78
H2887-5	ADJUSTABLE KEEPER ASSEMBLY	78
H2887-7	ADJUSTABLE KEEPER ASSEMBLY	78

H2887-9	ADJUSTABLE KEEPER ASSEMBLY	78
H2893-7	LATCH	78
H3044-1	LATCH KEEPER ASSEMBLY	78
H3855-5	LATCH KEEPER FAN	78
H3855-6	LATCH KEEPER FAN	78
H3855-7	LATCH KEEPER FAN	78
H3855-8	LATCH KEEPER FAN	78
H3856-3	LATCH KEEPER FAN	78
H3858-3	LATCH KEEPER FAN	78
H3917-7	LATCH	78
HC016	HEATER DRAIN VALVE	30
HFE95-20D10	COFFEE MAKER ESPRESSO	25
HG2030BE03	ADIRU - AIR DATA AND INERTIAL	34
HG2030BE04	ADIRU - AIR DATA AND INERTIAL	34
HSD100	INVERTER STATIC	25
HTE620196	UNION SLIDING	29
HTE620197	UNION SLIDING	29
HTE900162	VALVE FUEL CROSSFEED	28
HTE900209-001	VALVE ISOLATION	28
HTE900212	VALVE LOW PRESSURE FUEL	28
HTE900214-001	VALVE ISOLATION	28
J172ABM01	ACCELEROMETER UNIT VERTICAL	27
J172AFM03	ACCELEROMETER UNIT LATERAL	27
J540AI1-510	TOILET ASSY	38
J540AI1-700	TOILET ASSY	38
J540AI1-701	TOILET ASSY	38
J540AI2-300	TOILET ASSY	38
J540AI2-500	TOILET ASSY	38
J540AI2-510	TOILET ASSY	38
J540AI2-515	TOILET ASSY	38

J540AI2-520	TOILET ASSY	38
J540AI2-701	TOILET ASSY	38
J540AI4-100	GENERATOR VACUUM	38
J540AI6	VALVE CHECK	38
J540AI73	SENSOR LIQUID LEVEL	38
J540AI75-100	SENSOR DIFFERENTIAL PRESSURE	38
K274AAM0608	FCU - FLIGHT CONTROL UNIT	22
K282AAM0305	PRINTER	45
K282AAM0406	PRINTER	45
L83A13-610	WATER DRAIN VALVE WITH RE	28
L83A13-613	VALVE DRAIN WATER	28
L83A13-616	VALVE DRAIN WATER	28
L83A13-619	WATER DRAIN VALVE	28
L83A13-620	WATER DRAIN VALVE	28
L87-13-003	VALVE FLOAT	28
L93C100-651	COUPLING REFUEL	28
L93C100-655	COUPLING REFUEL	28
L95F100-604	PROTECTOR OVERPRESSURE	28
L95F100-605	PROTECTOR OVERPRESSURE	28
L95L90-601	PROTECTOR OVERPRESSURE	28
L95L90-602	PROTECTOR OVERPRESSURE	28
LA2B00300070000	FCSC - FLIGHT CONTROL SECON	27
LA2B00300A40000	FCSC - FLIGHT CONTROL SECON	27
LA2E20202T40000	FWC - FLHT WARNING COMP T4	31
LA2E20202T50000	FWC - FLHT WARNING COMP T5	31
LA2E20202T70000	FWC - FLHT WARNING COMP T7	31
LA2E50700100000	SDAC - SYS DATA ACQUI C9	31
LA2E50700110000	SDAC - SYS DATA ACQUI C9	31
LA2E50700C40000	SDAC - SYS DATA ACQUI C9	31
LA2E50700C70000	SDAC - SYS DATA ACQUI C9	31

LA2E50700C80000	SDAC - SYS DATA ACQUI C9	31
LA2E50700C90000	SDAC - SYS DATA ACQUI C9	31
LA2E90606HM0100	ECP - ECAM CONTROL PANEL	31
LA2E90707HM0100	ECP - ECAM CONTROL PANEL	31
LA2E90808HM0100	ECP - ECAM CONTROL PANEL	31
LA2G007000A0000	CMC - CENTRAL MAINTENANCE	45
LA2G007001A0000	CMC - CENTRAL MAINTENANCE	45
LA2G007001C0000	CMC - CENTRAL MAINTENANCE	45
LA2G007001D0000	CMC - CENTRAL MAINTENANCE	45
LA2H60300HM0100	BTMU - BRAKE TEMPERATURE	32
LA2K1A100DF0000	FCPC - FLIGHT CONTROL PRIMARY	27
LA2K1A100DG0000	FCPC - FLIGHT CONTROL PRIMARY	27
LA2K2B100DF0100	OBRM - FCPC	27
LA2K2B100DF0200	OBRM - FCPC	27
LA2K2B100DG0000	FCPC - FLIGHT CONTROL PRIMARY	27
LA2K2B100DG0100	OBRM - FCPC	27
LA2K2B100DG0200	OBRM - FCPC	27
LA2K2B100DH0000	FCPC - FLIGHT CONTROL PRIMARY	27
LA2K2B100DH0100	OBRM - FCPC	27
LA2K2B100DH0200	OBRM - FCPC	27
LA2K2B100GC0100	OBRM - FCPC	27
LA2K2B100GC0200	OBRM - FCPC	27
LA2L51415HM0100	BCL - BATTERY CHARGE LIMITE	24
LA2L51416HM0100	BCL - BATTERY CHARGE LIMITE	24
LA2L51417HM0100	BCL - BATTERY CHARGE LIMITE	24
LA2L51518HM0100	BCL - BATTERY CHARGE LIMITE	24
LA2L51619HM0100	BCL - BATTERY CHARGE LIMITE	24
LA2R00100HM0100	CONTROL BOX REMOTE ATC	34
LA2T0G20503B040	ATSU - AIR TRAFFIC SERVICES	46
LA2T0G20503B050	ATSU - AIR TRAFFIC SERVICES	46

LA2T0G20705C070	ATSU - AIR TRAFFIC SERVICES	46
LH1459702	BELLOWS ASSY	36
MF20-534	MASK FULL FACE	35
MXP801-11	STOWAGE BOX ASSY	35
N40-1B10100-101	HANDSET COCKPIT	23
N40-1B10125-101	HANDSET COCKPIT	23
N40-1B10150-101	HANDSET COCKPIT	23
N40-1B30203-102	HANDSET CABIN	23
N40-1B40203-102	HANDSET CABIN	23
NP175201-3	WINDSHIELD LH	56
NP175201-4	WINDSHIELD RH	56
NP175201-5	WINDSHIELD LH	56
NP175201-6	WINDSHIELD RH	56
NP175232-1	WINDOW SLIDING LH	56
NP175232-2	WINDOW SLIDING RH	56
NP175233-1	WINDOW FIXED LH	56
NP175233-2	WINDOW FIXED RH	56
P436A0001-01	VALVE CHANGE OVER NLG	32
P93A19-203	PUMP FUEL	28
P93A19-204	PUMP FUEL	28
P95B06-201	PUMP-HAND	29
P95B06-204	PUMP HAND	29
P95B06-206	PUMP HAND	29
PC01801	TRANSFORMER CURRENT	24
PC02001-01	TRANSFORMER CURRENT	24
PG1152AC05	ADM-AIR DATA MODULE	34
PG1152BC02	ADM-AIR DATA MODULE	34
PMC1102-02	DETECTOR SMOKE	26
PMC1103-03	DETECTOR SMOKE	26
PMC3101-01	DETECTOR SMOKE	26

PPA1103-00	DETECTOR SMOKE	26
PPA1202-00	DETECTOR SMOKE LAVATORY	26
PPA1203-00	DETECTOR SMOKE LAVATORY	26
PPA1204-00	DETECTOR SMOKE LAVATORY	26
PPA2100-00	DETECTOR SMOKE CARGO	26
PPA2101-00	DETECTOR SMOKE CARGO	26
PPC1200-00	DETECTOR SMOKE LAVATORY	26
QA06753-03	FILTER HALON	26
QB0406-00	HOUSING FILTER FWD	21
RA00755A	RESTRICTOR HYDRAULIC	29
RAI2810M0505	SDCU-SMOKE DETECTION	26
RAI2811M0106	SDCU-SMOKE DETECTION	26
RC0200A00	HEATER	21
RCB3546AC01	CONTROL UNIT CVR	23
RCF6708	REGULATOR TRANSMITTER	35
RDAA7795-54	MONITOR LCD	23
RDAX7675-51	PRAM-PRERECORDED ANNOUNCE	23
RPCU9167-01	CONTROL UNIT	21
RPP137-1A	CONTROL UNIT WATER LEVEL	38
RU1502U01	FAN WHEEL BRAKE	32
S1820513-02	PANEL REMOTE CONTROL	25
S1820513-15	PANEL REMOTE CONTROL	25
S1821502-02	ELT- EMERGENCY LOCATOR	25
S4-3300346-02	ACTUATOR DOOR CARGO	52
S4-3300346-04	ACTUATOR DOOR CARGO	52
S4-3300935	ACTUATOR DOOR MLG	32
S4-3300955	ACTUATOR DOOR NLG	32
S4-3402180	VALVE ELECTRO SELECTOR	52
S4-4500271	STRUT SPRING RAT	29
S72-1712-12	ANTENNA ADF	34

SC4710	SERVOACTUATOR YAW DAMPER	27
SC4710-1	SERVOACTUATOR YAW DAMPER	27
SC4800-104	SERVOCONTROL ELEVATOR	27
SC4800-114	SERVOCONTROL ELEVATOR	27
SC4800-9	SERVOCONTROL ELEVATOR	27
SC4800-94	SERVOCONTROL ELEVATOR	27
SC4810-5	SERVOCONTROL ELEVATOR	27
SP2979G	CONTROLLER LIGHTING	33
SP2985B	LIGHT UNIT	33
SP3000D	CONTROLLER-LIGHTING	33
SP3062	TRANSFORMER RECTIFIER	24
SP3062A	TRANSFORMER RECTIFIER	24
SP3062C	TRANSFORMER RECTIFIER	24
SPSA340-1-4-1	WINDSHIELD RH	56
SPSA340-1-5-2	WINDSHIELD RH	56
SPSA340-2-4-1	WINDSHIELD LH	56
SPSA340-2-5-2	WINDSHIELD LH	56
SPSA340-3-1-1	WINDOW SLIDING RH	56
SPSA340-4-1-1	WINDOW SLIDING LH	56
SPSA340-5-1-1	WINDOW FIXED RH	56
SPSA340-6-1-1	WINDOW FIXED LH	56
ST105-517	STRUT HOLD OPEN ROD	78
ST105-525	STRUT HOLD OPEN ROD	78
ST106-519	STRUT HOLD OPEN ROD	78
TA9115-00	TOILET ASSY	25
TA9125-00	TOILET ASSY	25
TAAI3-03CE20-01	SEAT FIRST OFFICER	25
TAAI3-04IM20-01	SEAT THIRD OCCUPANT	25
TAAI3-04IM30-01	SEAT THIRD OCCUPANT	25
TAAI3-04IM40-01	SEAT THIRD OCCUPANT	25

TAAI3-04IM50-01	SEAT THIRD OCCUPANT	25
TAAI3-14IM20-01	SEAT THIRD OCCUPANT	25
TLS755-01-0101B	MMR - MULTI MODE RECEIVER	34
TLS755-01-0102A	MMR - MULTI MODE RECEIVER	34
TP0714033	SWITCH-PRESSURE	26
TY1727-20A	T/R OPENING ACTUATOR	78
TY1728-50A	MANIFOLD	78
TY1915-21A	T/R HYDRAULIC CTR UNIT	78
TY1916-02A	T/R DIRECTIONAL CTR UNIT	78
TY1917-20B	T/R PRIMARY LOCK	78
TY1931-20A	T/R ROT VARIABLE TRANSDUCER	78
TY2000-20A	T/R ROT VARIABLE TRANSDUCER	78
TY2008-01A	T/R ELEC JUNCTION BOX	78
TY2109-02A	T/R PWR CONDITIONING MOD	78
TY3409-01A	ACTUATOR ROTARY	32
VA4110	FAN RECIRCULATION	21
VD3810	FAN MIXED FLOW	21
VD3820	FAN RECIRCULATION	21
VD3820-01	FAN RECIRCULATION	21
VD3901-00	FAN RECIRCULATION	21
VD3909-00	FAN RECIRCULATION	21
VD3920	FAN EXTRACTION	21
VF1620B00	VALVE OVBD EXTRACTION	21
VFT210B00	VALVE SKIN AIR	21
VP1860AA0	VALVE FLOOR EXTRACTION	21
VP1860C00	VALVE FLOOR EXTRACTION	21
VR4100-02	FAN RECIRCULATION	21
VR4100-03	FAN RECIRCULATION	21
VR4100-04	FAN RECIRCULATION	21
VSC8992	CONTROLLER VACUUM SYSTEM	38

VSC8994	CONTROLLER VACUUM SYSTEM	38
VT061-9A	TRANSMITTER CONTENTS	38
VT061-9B	TRANSMITTER CONTENTS	38
VT442-2	INDICATOR WATER QUANTITY	38
VT476-11	INDICATOR QUANTITY	38
VTF00110	LINK ASSY ADJUSTABLE	78
WTH9394-00	WATER TANK HEATER	30
WV9135-01	VALVE WATER SHUTOFF	25
X8902-1	HEATER UNIT FAN	21
Y025-01	INDICATOR RUDDER TRIM	27
Z011H0000116	DIRECTOR CIDS	23
Z011H0001116	DIRECTOR CIDS	23
Z011H000142A	DIRECTOR CIDS	23
Z011H0002116	DIRECTOR CIDS	23
Z011H000240A	DIRECTOR CIDS	23
Z011H000242A	DIRECTOR CIDS	23
Z013H000051A	DIRECTOR CIDS	23
Z013H000151A	DIRECTOR CIDS	23
Z013H000253A	DIRECTOR CIDS	23
Z013H011260A	DIRECTOR CIDS	23
Z031H0000110	DEU - DECODER ENCODER UNIT	23
Z031H0001110	DEU - DECODER ENCODER UNIT	23
Z031H0002110	DEU - DECODER ENCODER UNIT	23
Z033H0000110	DEU - DECODER ENCODER UNIT	23
Z033H0001110	DEU - DECODER ENCODER UNIT	23
Z033H0002111	DEU - DECODER ENCODER UNIT	23
Z033H0003112	DEU - DECODER ENCODER UNIT	23
Z041H0000110	DEU - DECODER ENCODER UNIT	23
Z041H000140A	DEU - DECODER ENCODER UNIT	23
Z041H000240B	DEU - DECODER ENCODER UNIT	23

Z043H000050A	DEU - DECODER ENCODER UNIT	23
Z043H000351A	DEU - DECODER ENCODER UNIT	23
Z063H000058B	OBRM - ONBOARD REPLACEABLE	23
Z063H000065B	OBRM - ONBOARD REPLACEABLE	23
Z111H0033130	AIP - ATTENDANT INDICATION	23
Z111H0033131	AIP - ATTENDANT INDICATION	23
Z111H0037131	AIP - ATTENDANT INDICATION	23
Z121H0002110	AAP - ADDITIONAL ATTENDANT	25
Z121H0050110	AAP - ADDITIONAL ATTENDANT	23
Z121H0080110	AAP - ADDITIONAL ATTENDANT	23
Z121H0080111	AAP - ADDITIONAL ATTENDANT	23
Z121H0111110	AAP - ADDITIONAL ATTENDANT	25
Z121H0112110	AAP - ADDITIONAL ATTENDANT	25
Z121H0130111	AAP - ADDITIONAL ATTENDANT	23
Z121H0131110	AAP - ADDITIONAL ATTENDANT	23
Z121H0132111	AAP - ADDITIONAL ATTENDANT	23
Z121H0173111	AAP - ADDITIONAL ATTENDANT	23
Z121H0174111	AAP - ADDITIONAL ATTENDANT	23
Z121H0175111	AAP - ADDITIONAL ATTENDANT	23
Z121H0183110	AAP - ADDITIONAL ATTENDANT	23
Z121H0184110	AAP - ADDITIONAL ATTENDANT	23
Z121H0186111	AAP - ADDITIONAL ATTENDANT	23
Z121H0202110	AAP - ADDITIONAL ATTENDANT	25
Z121H0203111	AAP - ADDITIONAL ATTENDANT	23
Z121H0204111	AAP - ADDITIONAL ATTENDANT	23
Z121H0209111	AAP - ADDITIONAL ATTENDANT	23
Z121H0211110	AAP - ADDITIONAL ATTENDANT	23
Z121H0212110	AAP - ADDITIONAL ATTENDANT	23
Z121H0B85111	AAP - ADDITIONAL ATTENDANT	23
Z121H0B86111	AAP - ADDITIONAL ATTENDANT	23

Z121H0D04111	AAP - ADDITIONAL ATTENDANT	23
Z121H0D09111	AAP - ADDITIONAL ATTENDANT	23
Z121H0D58111	AAP - ADDITIONAL ATTENDANT	23
Z121H0D59111	AAP - ADDITIONAL ATTENDANT	23
Z121H0D60111	AAP - ADDITIONAL ATTENDANT	23
Z121H0D61111	AAP - ADDITIONAL ATTENDANT	23
Z121H0G63111	AAP - ADDITIONAL ATTENDANT	23
Z131H0066113	FAP - FORWARD ATTENDANT PANEL	23
Z131H0402114	FAP - FORWARD ATTENDANT PANEL	23
Z131H0702114	FAP - FLIGHT ATTENDANT PANEL	23
Z131H0729116	FAP - FLIGHT ATTENDANT PANEL	23
Z133H001351A	FAP - FLIGHT ATTENDANT PANEL	23
Z133H001651A	FAP - FLIGHT ATTENDANT PANEL	23
Z133H061751A	FAP - FLIGHT ATTENDANT PANEL	23
Z145H0022110	FAP - FORWARD ATTENDANT PANEL	23
Z145H0031111	FAP - FORWARD ATTENDANT PANEL	23
Z145H004A120	FAP - FORWARD ATTENDANT PANEL	23
Z145H0420110	FAP - FORWARD ATTENDANT PANEL	23
Z145H0422110	FAP - FORWARD ATTENDANT PANEL	23
Z145H043A111	FAP - FORWARD ATTENDANT PANEL	23
Z242H0000222	BOX SEAT INTERFACE	25
Z307H0100110	BOX LOUDSPEAKER	23
Z310H2411111	PSU - PASSENGER SERVICE UNIT	23
Z310H2421111	PSU - PASSENGER SERVICE UNIT	23
Z313H02AA021	PSU - PASSENGER SERVICE UNIT	23
Z313H02LA021	PSU - PASSENGER SERVICE UNIT	23
Z313H03LA021	PSU - PASSENGER SERVICE UNIT	23
Z313H0BA0021	PSU - PASSENGER SERVICE UNIT	23
Z313H0BHA021	PSU - PASSENGER SERVICE UNIT	23
Z314H04A0021	PSU - PASSENGER SERVICE UNIT	23

Z314H04AA021	PSU - PASSENGER SERVICE UNIT	23
Z314H0DA0021	PSU - PASSENGER SERVICE UNIT	23
Z314H0DHA021	PSU - PASSENGER SERVICE UNIT	23
Z339H0103421	PSU - PASSENGER SERVICE UNIT	23
Z346H0100110	PANEL ASSY OUTLET MEDICAL	25
Z350H0401110	PISA - PASSENGER INTERFACE	23
Z351H0000110	PISA - PASSENGER INTERFACE	23
Z445H000080C	CONVERTER DATA	26
Z445H000080D	CONVERTER DATA	26
Z452H0000110	SWITCH HEAD END	46
Z453H0000110	CWLU - CABIN WIRELESS LAN UNIT	46
Z905H0000110	INSULATION UNIT	23
Z905H0001110	INSULATION UNIT	23
Z905H0010110	INSULATION UNIT	23
Z905H0011110	INSULATION UNIT	23
ZAW382-01	TRANSDUCER PRESSURE	29
ZAW623-01	TRANSDUCER PRESSURE	29
ZRA380-00	TRANSDUCER PRESSURE	36
ZRA691-00	TRANSDUCER PRESSURE	36