



BOMBARDIER Q400 - CAPABILITY LIST

SOURCING / PROCUREMENT / REPAIR

Please address your requests and orders to sales@spareways.com
<http://www.spareways.net/>

PARTNUMBER	DESCRIPTION	ATA
00-13937-02	MOLDED ASSY FWD TOP	72
00-13938-02	MOLDED ASSY AFT TOP	72
00-13944-02	MOLDED ASSY AFT SIDE	72
00-13965-01	MOLDED ASSY-AFT	72
00-13977-01	RESERVOIR ASSY	71
00-14050-01	MOLDED ASSY FWD SIDE	72
00-14067-01	LINK ASSY FWD SIDE ISOLATOR	72
0218-0032-1	VALVE DRAIN	38
028-069-003	PROBE FUEL QUANTITY	28
028-069-004	PROBE FUEL QUANTITY	28
028-069-006	PROBE FUEL QUANTITY	28
028-069-007	PROBE FUEL QUANTITY	28
028-069-009	PROBE FUEL QUANTITY	28
028-069-011	PROBE FUEL QUANTITY	28
028-069-012	PROBE FUEL QUANTITY	28
028-069-015	PROBE FUEL QUANTITY	28
028-069-111	PROBE FUEL QUANTITY	28
064-01073-0102	RECEIVER HF	23

0080-0035-1	NOSEWHEEL POWER STEERING UNIT	32
0080-0035-1003	NOSEWHEEL POWER STEERING UNIT	32
0080-0035-3	NOSEWHEEL POWER STEERING UNIT	32
0080-0035-5	NOSEWHEEL POWER STEERING UNIT	32
0080-0035-7	NOSEWHEEL POWER STEERING UNIT	32
0218-0032-1	VALVE ASSY	38
07802	WINDSHIELD LH	56
07803	WINDSHIELD RH	56
066-01101-0060	RECEIVER VHF - NAV	34
066-01105-0010	RECEIVER ADF - NAV	34
066-01107-0021	TRANSCEIVER DME - NAV	34
066-01143-2101	TRANSPONDER MODE S	34
066-01146-1211	TCAS PROCESSOR	34
066-01153-0101	RADIO ALTIMETER	34
071-01548-0100	TCAS ANTENNA	34
1FA15009-5	SWIVEL BRAKE ASSY	32
1FA15009-6	SWIVEL LOCK ASSY	32
10-1096-01	ELEMENT SENSING FIRE DETECTION	26
10-1096-02	ELEMENT SENSING FIRE DETECTION	26
10-1097-02	ELEMENT SENSING FIRE DETECTION	26
10-1098	ELEMENT SENSING FIRE DETECTION	26
10-1099	ELEMENT SENSING FIRE DETECTION	26
10-250-9B2D	ANTENNA KIT VOR - LOC	34
1017097-1	SWITCH OVERTEMPERATURE	77
103-1190	PANEL VHF STANDBY CONTROL	23
10706	ANTENNA GPS	34
1096085-1	UNIT POWER PROTECTION AC	24
1095998-1	CONTACTOR 150A	24
1095999-1	CONTACTOR 100A	24
1096224-2	CONTACTOR-SPST 400A	24

1152092-4	GENERATOR CONTROL UNIT	24
1152106-2	STARTER DC GENERATOR	24
1152106-3	STARTER DC GENERATOR	24
1152108-6	GENERATOR CONTROL UNIT	24
1152110-2	TRANSFORMER RECTIFIER	24
1152112-2	BATTERY 40AH	24
1152218-6	GENERATOR AC	24
1152222-5	ELECTRICAL POWER CONTROL UNIT	24
1152224-5	BOX CONTACTOR STANDBY	24
1152268-1	BATTERY 17AH	24
1152400-2	STARTER DC GENERATOR	49
1152400-3	STARTER DC GENERATOR	49
1152400-4	STARTER DC GENERATOR	49
1152400-5	STARTER DC GENERATOR	49
1152862-3	FLIGHT SIGNAL CONDITIONING	31
11749500	FAN COOLING	21
130009G	ACTUATOR ELECTRIC MOTOR OPERATED	29
1374-102-100	EQAR	31
1406-01-1	UNIT DATA TRANSFER	34
14330-044	VACUUM GENERATOR	38
14330-050F	VACUUM GENERATOR	38
14330-062	VACUUM GENERATOR	38
14330-143	VACUUM GENERATOR	38
14330-144	VACUUM GENERATOR	38
14330-375	VACUUM GENERATOR	38
15900-001	TOILETT ASSY	38
15900-004	TOILETT ASSY	38
15900-005	TOILETT ASSY	38
15900-008	TOILETT ASSY	38
15900-223	MOTOR PUMP FILTER	38

171800-07	SIDE WINDOW HEATED LH	56
171800-09	SIDE WINDOW HEATED LH	56
171800-12	SIDE WINDOW RH	56
171900-010	SIDE WINDOW RH	56
174260-08	MASK OXYGEN CREW	35
174660-08	MASK CREW OXYGEN FULL FACE	35
176233-50	CYLINDER CREW OXYGEN	35
176234-40	CYLINDER ASSY	35
176961-14	BOTTLE OXYGEN FIRST AID	35
179427-2	SENSOR PRESSURE	77
1827-1	POWER SUPPLY UNIT	24
24E507009G03	WATER HEATER	38
24E507040G01	WATER HEATER	38
24E507040G02	WATER HEATER	38
24E507040G03	WATER HEATER	38
24E507040G04	WATER HEATER	38
24E507040G05	WATER HEATER	38
24E507040G06	WATER HEATER	38
227CC02AY00	CONTACTOR SPST 400A	24
2940034-201	VALVE WATER DRAIN	28
2950004-201	ACTUATOR ASSY	28
2950004-202	ACTUATOR ASSY	28
2950016-103	VENT VALVE	28
2960004-101	VALVE SOLENOID	28
2960005-101	VALVE SHUT OFF	28
2960006-101	ADAPTOR REFUEL - DEFUEL	28
2960008-102	PUMP EJECTOR	28
2960018-101	VALVE CHECK	28
2960027-101	VALVE SHUT OFF	28
2960032-101	VALVE FLAPPER	28

2960033-102	VALVE VENT FLOAT	28
2960042-101	VALVE SHUT OFF ENGINE FEED	28
2960044-101	VALVE SHUT OFF REFUEL - DEFUEL	28
2962001-101	VALVE SHUT OFF	28
2962003-101	VALVE SHUT OFF REFUEL - DEFUEL	28
266E0305-00	UNDERWATER LOCATOR BEACON	31
266E0305-01	UNDERWATER LOCATOR BEACON	31
2-1605	BRAKE ASSY	32
2-1605-1	BRAKE ASSY	32
2-1605-2	BRAKE ASSY	32
3-1573-1	WHEEL MLG	32
3-1574	WHEEL NLG	32
3R1770	VALVE RELIEF	32
30-1840-5	LIGHT LOGO	33
30-2554-1	LIGHT POSITION	33
30-2554-2	LIGHT POSITION	33
30-2555-1	LIGHT TAIL POSITION	33
30-2557-1	FLOODLIGHT	33
30-2557-2	FLOODLIGHT	33
30-2557-3	LIGHT ENGINE INSPECTION LH	33
30-2557-4	LIGHT ENGINE INSPECTION RH	33
30-2558-3	LIGHT WING INSPECTION LH	33
30-2558-4	LIGHT WING INSPECTION RH	33
30-2610-1	ANTI COLLISION LIGHT	33
30-2623-3	LIGHT RED LAMP GROUND	33
30145-0301	PROXIMITY SENSOR ELECTRONIC UNIT	32
30145-0401	PROXIMITY SENSOR ELECTRONIC UNIT	32
3046771-03	SEPARATOR P3 AIR	75
3046885-01	DISK HP TURBINE	72
3046886-01	DISK POWER TURBINE 1 STAGE	72

3047121-05	PUMP OIL	79
3047237-01	SENSOR TEMPERATURE	77
3047237-02	SENSOR TEMPERATURE	77
3047251-01	SENSOR SPEED	77
3047252-01	SENSOR TORQUE	77
3047267-01	SENSOR SPEED	77
3047586-01	HP TURBINE FRONT COVER	72
3047993-01	HP TURBINE REAR COVER	72
3047604-04	VALVE FLOW DIVIDER	73
3047683-05	VALVE ASSY INTERSTAGE BLEED	75
3047683-06	VALVE ASSY INTERSTAGE BLEED	75
3047683-07	VALVE ASSY INTERSTAGE BLEED	75
3047683-08	VALVE ASSY INTERSTAGE BLEED	75
3047767-01	ADAPTER AIR SUPPLY	75
3047966-05	VALVE ASSY INTERSTAGE BLEED	75
3048148-01	SENSOR OIL TEMPERATURE	77
3048221-01	THERMOCOUPLE	77
3048223-01	ROTOR COMPRESSOR 3 STAGE	72
3048361-01	HPT BLADE	72
3048459-01	DISK POWER TURBINE 2 STAGE	72
3048509-01	FUEL MANIFOLD STARBOARD	73
3048510-01	FUEL MANIFOLD STARBOARD	73
3048543-01	COVER LP TURBINE FRONT	72
3048663-01	DISK LP TURBINE	72
3048672-01	ROTOR COMPRESSOR	72
3048872-01	ROTOR COMPRESSOR 2 STAGE	72
3049127-01	IMPELLER CENTRIFUGAL HP	72
3049409-02	HEATER FUEL	75
3049409-03	HEATER FUEL	75
3049409-04	HEATER FUEL	75

3049409-05	HEATER FUEL	75
3049409-06	HEATER FUEL	75
3053567-01	SENSOR LEVEL ONE	79
3071091-01	ROTOR COMPRESSOR 1 STAGE	72
3071954-01	FUEL NOZZLE	72
3076002-01	SENSOR TEMPERATURE	77
3076465-01	FUEL NOZZLE	72
3100580-001	VALVE CONTROL UNIT	38
3122406-09	ENGINE MONITOR UNIT	77
3122413-07	EXCITER IGNITION	74
3122419-10	FUEL METERING UNIT	73
3122435-02	TRANSDUCER PRESS AIR	75
3122444-02	VALVE CHECK	75
3122448-01	SENSOR OIL PRESSURE	79
351-38505-004	PANEL ASSY CAUTION & WARNING	31
351-38507-002	PANEL ADVISORY CONTROL UNIT	31
367-118-002	COMPUTER FUEL QTY	28
367-119-002	UNIT HIGH LEVEL CONTROL	28
390500-1007	PCU RUDDER	27
390500-1009	PCU RUDDER	27
390500-1011	PCU RUDDER	27
390600-1005	ELEVATOR ACTUATOR PCU	27
390600-1007	ELEVATOR ACTUATOR PCU	27
390600-1009	ELEVATOR ACTUATOR PCU	27
390700-1007	SPOILER ACTUATOR PCU	27
390700-1009	SPOILER ACTUATOR PCU	27
395800-1005	SPOILER LIFT DUMP VALVE	27
395800-1007	SPOILER LIFT DUMP VALVE	27
395900-1001	COMPENSATOR ELEVATOR PCU	29
396000-1005	SOLENOID VALVE	27

398500-1009	FCECU - FLIGHT CONTROL ELECTRONIC	22
399200-1005	PITCH FEEL TRIM ASSY	27
399300-1009	PITCH FEEL ACTUATOR LEFT	27
399300-1010	PITCH FEEL ACTUATOR RIGHT	27
399400-1013	PITCH TRIM ACTUATOR	27
399500-1007	RUDDER	27
399600-1007	ACTUATOR RUDDER	27
399700-1005	SPRING CENTERING ASSY	27
399800-1007	ACTUATOR AIRLERON TRIM	27
399900-1001	LINEAR VARIABLE DIFFERENTIAL	27
400-2636-01	OVEN	25
4100S005-01	DUAL DISTRIBUTING VALVE	30
4100S005-02	DUAL DISTRIBUTING VALVE	30
4100S005-03	DUAL DISTRIBUTING VALVE	30
4100S005-04	DUAL DISTRIBUTING VALVE	30
4100S007-01	VALVE SHUT OFF ISOLATION	30
4100S014	RESERVOIR	52
4100S018-06	TIMER & MONITOR UNIT	30
4100S018-07	TIMER & MONITOR UNIT	30
4100S019-07	PROBE DETECTOR ICE	30
4100S019-08	PROBE DETECTOR ICE	30
4100S020-02	ANTI ICE CONTROLLER	30
4100S028-04	AIR INTAKE ADAPTER HEATHER	30
4100S031-01	VALVE DOOR SEAL CONTROL	52
406300-05-01	ECU	32
406330-03-01	HANDLE STEERING NOSEWHEEL	32
407D010001	AIR JET PUMP	21
4101910A	RECIRCULATION FAN	21
412700-1001	RUDDER VALVE SHUT OFF	27
41700-1001	VALVE SHUT OFF	27
4213403	STANDBY POWER UNIT	29

420-00332-501	AHRS - ATTITUDE HEADING REFERENCE UNIT	34
420-00346-001	AHRS CONTROL PANEL	34
420-01867-200	AHRS REMOTE MEMORY MODULE	34
425-0001-7	COFFEE MAKER	25
425-0001-11	COFFEE MAKER	25
4363698	MOTOR CONVERTER ASSY LH	30
4363727	MOTOR CONVERTER ASSY RH	30
4363741A	SWITCH ROTARY	30
4426X2-12	RADOME ASSY	53
446253-1	SMOKE DETECTOR	26
4501004	TURBINE WHEEL	49
4503067A	APU	49
4503067B	APU	49
4503069E	FADEC APU	49
4503069F	FADEC APU	49
4503139C	CONTROL AY FUEL	49
4503310	COMPRESSOR WHEEL IMPELLER	49
4510-1	BEVERAGE MAKER	25
4510-2	BEVERAGE MAKER	25
4510-28UG-00	BEVERAGE MAKER	25
46100-29	SHOCK STRUT MLG	32
46100-31	SHOCK STRUT MLG	32
46100-33	SHOCK STRUT MLG	32
46100-35	SHOCK STRUT MLG	32
46100-37	SHOCK STRUT MLG	32
46100-39	SHOCK STRUT MLG	32
46100-41	SHOCK STRUT MLG	32
46100-43	SHOCK STRUT MLG	32
46100-45	SHOCK STRUT MLG	32
46100-47	SHOCK STRUT MLG	32
46100-49	SHOCK STRUT MLG	32
46100-51	SHOCK STRUT MLG	32

46100-53	SHOCK STRUT MLG	32
46100-55	SHOCK STRUT MLG	32
46100-57	SHOCK STRUT MLG	32
46100-59	SHOCK STRUT MLG	32
46165-1	ELECTRICAL HARNESS MLG	32
46165-3	ELECTRICAL HARNESS MLG	32
46170-1	ELECTRICAL HARNESS MLG	32
46170-3	ELECTRICAL HARNESS MLG	32
46170-5	ELECTRICAL HARNESS MLG	32
46350-7	YOKE ASSY MLG	32
46350-9	YOKE ASSY MLG	32
46350-11	YOKE ASSY MLG	32
46350-13	YOKE ASSY MLG	32
46350-15	YOKE ASSY MLG	32
46400-15	STABILIZED BRACE ASSY MLG	32
46400-17	STABILIZED BRACE ASSY MLG	32
46400-21	STABILIZED BRACE ASSY MLG	32
46400-23	STABILIZED BRACE ASSY MLG	32
46400-25	STABILIZED BRACE ASSY MLG	32
46400-27	STABILIZED BRACE ASSY MLG	32
46400-29	STABILIZED BRACE ASSY MLG	32
46450-3	ELECTRICAL HARNESS	32
46450-5	ELECTRICAL HARNESS	32
46450-7	ELECTRICAL HARNESS	32
46460-3	ELECTRICAL HARNESS	32
46460-5	ELECTRICAL HARNESS	32
46460-7	ELECTRICAL HARNESS	32
46500-1	UPLOCK ASSY MLG	32
46500-3	UPLOCK ASSY MLG	32
46500-5	UPLOCK ASSY MLG	32
46500-7	UPLOCK ASSY MLG	32
46500-9	UPLOCK ASSY MLG	32

46550-7	RETRACTION ACTUATOR ASSY	32
46550-9	RETRACTION ACTUATOR ASSY	32
46550-11	RETRACTION ACTUATOR ASSY	32
46550-13	RETRACTION ACTUATOR ASSY	32
46550-15	RETRACTION ACTUATOR ASSY	32
46550-17	RETRACTION ACTUATOR ASSY	32
46550-19	RETRACTION ACTUATOR ASSY	32
46550-21	RETRACTION ACTUATOR ASSY	32
46550-23	RETRACTION ACTUATOR ASSY	32
46550-25	RETRACTION ACTUATOR ASSY	32
46550-27	RETRACTION ACTUATOR ASSY	32
46600-3	LOCK ACTUATOR ASSY MLG	32
46600-5	LOCK ACTUATOR ASSY MLG	32
46600-7	LOCK ACTUATOR ASSY MLG	32
46600-9	LOCK ACTUATOR ASSY MLG	32
46600-11	LOCK ACTUATOR ASSY MLG	32
46650-1	AUXILIARY ACTUATOR ASSY MLG	32
46650-1001	AUXILIARY ACTUATOR ASSY MLG	32
46650-3	AUXILIARY ACTUATOR ASSY MLG	32
46830-3	DOOR ACTUATOR ASSY MLG	32
46830-5	DOOR ACTUATOR ASSY MLG	32
46830-7	DOOR ACTUATOR ASSY MLG	32
4689709A-02246	TRANSCEIVER VHF	23
47150-5	ELECTRICAL HARNESS NLG	32
47150-7	ELECTRICAL HARNESS NLG	32
47150-9	ELECTRICAL HARNESS NLG	32
47151-5	ELECTRICAL HARNESS NLG	32
47152-5	ELECTRICAL HARNESS NLG	32
47181-1	NOSEWHEEL POWER STEERING UNIT	32
47181-3	NOSEWHEEL POWER STEERING UNIT	32
47181-5	NOSEWHEEL POWER STEERING UNIT	32
47200-9	SHOCK STRUT NLG	32

47200-11	SHOCK STRUT NLG	32
47200-13	SHOCK STRUT NLG	32
47200-15	SHOCK STRUT NLG	32
47200-17	SHOCK STRUT NLG	32
47200-19	SHOCK STRUT NLG	32
47200-21	SHOCK STRUT NLG	32
47200-23	SHOCK STRUT NLG	32
47200-25	SHOCK STRUT NLG	32
47200-27	SHOCK STRUT NLG	32
47200-29	DRAG BRACE NLG	32
47200-31	DRAG BRACE NLG	32
47201-1	ELECTRICAL HARNESS NLG	32
47201-3	ELECTRICAL HARNESS NLG	32
47201-5	ELECTRICAL HARNESS NLG	32
47201-7	ELECTRICAL HARNESS NLG	32
47202-1	ELECTRICAL HARNESS NLG	32
47202-3	ELECTRICAL HARNESS NLG	32
47300-1	DRAG STRUT NLG	32
47300-3	DRAG STRUT NLG	32
47300-5	DRAG STRUT NLG	32
47300-7	DRAG STRUT NLG	32
47300-9	DRAG STRUT NLG	32
47300-11	DRAG STRUT NLG	32
473597-15	SMOKE DETECTOR	26
473872-03	SMOKE DETECTOR	26
473879-1	FIRE EXTINGUISHER	26
473880-1	FIRE EXTINGUISHER	26
473951-1	FIRE EXTINGUISHER	26
473951-2	FIRE EXTINGUISHER	26
47390-1	ELECTRICAL HARNESS NLG	32
47390-3	ELECTRICAL HARNESS NLG	32
47391-1	ELECTRICAL HARNESS NLG	32

47391-3	ELECTRICAL HARNESS NLG	32
47400-1	ACTUATOR LOCK NLG	32
47400-3	ACTUATOR LOCK NLG	32
474033-1	FIRE EXTINGUISHER	26
47500-3	RETRACTION ACTUATOR NLG	32
47500-5	RETRACTION ACTUATOR NLG	32
47500-7	RETRACTION ACTUATOR NLG	32
47500-9	RETRACTION ACTUATOR NLG	32
47830-1	ACTUATOR ASSY DOOR	32
48111-1	POTENTIOMETER RUDDER	32
48150-5	STEERING CONTROL MANIFOLD	32
48150-7	STEERING CONTROL MANIFOLD	32
48150-9	STEERING CONTROL MANIFOLD	32
48300-3	VALVE SELECTOR	32
48301-3	VALVE BYPASS	32
48302-5	VALVE SOLENOID	32
48303-103	VALVE MECHANICAL SEQUENCE	32
48303-5	VALVE MECHANICAL SEQUENCE	32
48303-7	VALVE MECHANICAL SEQUENCE	32
48904-1	BRAKE ACCUMULTOR	32
4950634	FILTER AY FUEL	49
4951070	EXCITER	49
4951121	PROBE SPEED SENSOR	49
4951680	SERVO BLEED AIR VALVE	49
4952304	SERVO BLEED AIR VALVE	49
4952375	SERVO BLEED AIR VALVE	49
4952829	SERVO BLEED AIR VALVE	49
4E3160-1	DRAIN MAST HEATED	38
50-0253-5	LIGHT AY TAXI	33
501-1770-04	ACTUATOR STICK PUSHER	27
501-1771-02	CAPSTAN STICK PUSHER	27
510312-1	DUAL DISTRIBUTING VALVE	30

510353	ISOLATOR VALVE SHUT OFF	30
51149-04	POWER TRANSFER UNIT HYD	29
51149-05	POWER TRANSFER UNIT HYD	29
5346-220-80-10	INDICATOR CABIN DUCT TEMP	21
540-0949-5	VALVE ASSY INTERSTAGE BLEED	75
540-0949-6	VALVE ASSY INTERSTAGE BLEED	75
540-0949-7	VALVE ASSY INTERSTAGE BLEED	75
540-0949-8	VALVE ASSY INTERSTAGE BLEED	75
540-1037-3	VALVE ASSY INTERSTAGE BLEED	75
540-1037-5	VALVE ASSY INTERSTAGE BLEED	75
5427-116-80-10	INDICATOR DE ICE PRESSURE	30
60-5025-1	EMERGENCY POWER SUPPLY	33
6007045	ANTI-SKID CONTROL UNIT	32
6007046-1	SKID CONTROL VALVE	32
6007047	TRANSDUCER WHEEL SPEED AP-781	32
6007049-4	VALVE CONTROL BRAKE	32
6007050-3	VALVE BRAKE PARKING	32
6007051-1	FUSE SHUTTLE ASSY	32
6007073	HAND PUMP PARKING BRAKE	32
613100-1001	VALVE SELECTOR LANDING GEAR	29
61-3800-1	BATTERY	33
64040-800-1	INDICATOR AIRSPEED STANDBY	31
66173-02	PUMP HYDRAULIC	29
66173-03	PUMP HYDRAULIC	29
66173-04	PUMP HYDRAULIC	29
66173-05	PUMP HYDRAULIC	29
66182-02	PUMP DC MOTOR DRIVEN HYDRAULIC	29
66182-03	PUMP DC MOTOR DRIVEN HYDRAULIC	29
666000459	PROBE DUAL PULSE ASSY	61
697037001	ACTUATOR HUB	61
697037211-18	BLADE & BEARING	61
697071003	BLADE & BEARING	61

697070241	BLADE & BEARING	61
697071245-18	BLADE & BEARING	61
697071256	BLADE & BEARING	61
697070241	HUB & ACTUATOR	61
697070600	HUB & ACTUATOR	61
697072003	OVERSPEED GOVERNOR	61
697072004	OVERSPEED GOVERNOR	61
697073003	PITCH UNIT CONTROL	61
697074004	BETA TUBES HYDRAULIC SYSTEM	61
697076004	FEATHERING PUMP	61
697079003	BRUSH BLOCK	61
699009003	TIMER MONITOR CONTROL UNIT	61
699018003	PROPELLER ELECTRONIC CONTROL	61
70-0180-3	CONTROL ASSY DIMMER	33
7008471-687	WEATHER RADAR CONTROL PANEL	34
7021450-601	WEATHER RADAR	34
72068000	OVEN	25
72068001	OVEN	25
7-3100-2	VALVE VENT SHUT OFF	21
7-3700-1	VALVE VENT SHUT OFF	21
731840	HYDRAULIC PUMP	29
7468-3	RESERVOIR HYDRAULIC	29
756722A	VALVE DE OILING	49
756722B	VALVE DE OILING	49
800600M03	ACTUATOR OIL COOLER DOOR	79
800600M04	ACTUATOR OIL COOLER DOOR	79
8055515-4504	DATA PRINTER PTA-45B	31
81150C020201	FWD SAFETY VALVE	21
81155B010101	VALVE AFT SAFETY	21
819300-7-008	FADEC	73
819300-7-009	FADEC	73
820100-3-005	ECS UNIT	49

820100-3-007	ECS UNIT	49
820902-3	VALVE FLOW CONTROL	21
820902-4	VALVE FLOW CONTROL	21
820902-5	VALVE FLOW CONTROL	21
820902-6	VALVE FLOW CONTROL	21
820905-3	HEAT EXCHANGER DUAL	21
820905-5	HEAT EXCHANGER DUAL	21
820906-3	AIR CYCLE MACHINE	21
820907-1	SWITCH OVERTEMPERATURE	21
820907-2	SWITCH OVERTEMPERATURE	21
820907-3	SWITCH OVERTEMPERATURE	21
820907-4	SWITCH OVERTEMPERATURE	21
820907-5	SWITCH OVERTEMPERATURE	21
820907-6	SWITCH OVERTEMPERATURE	21
820908-2	SWITCH DUCT LEAK OVERTEMPERATURE	21
820908-3	SWITCH DUCT LEAK OVERTEMPERATURE	21
820912-3	HEAT EXCHANGER CONDENSING	21
820910-2	CHECK VALVE	21
820914-2	VALVE BYPASS	21
820914-3	VALVE BYPASS	21
820914-5	VALVE BYPASS	21
820914-6	VALVE BYPASS	21
820925	VALVE SHUTOFF TURBINE	21
820925-1	VALVE SHUTOFF TURBINE	21
820926-2	FAN BYPASS	21
820927-2	CHECK VALVE	21
820934-2	CHECK VALVE	21
820939-1	VALVE DISTRIBUTION DAMPER	21
820939-2	VALVE DISTRIBUTION DAMPER	21
820948-2	CHECK VALVE	21
820950	WATER COLLECTOR	21
820950-2	WATER COLLECTOR	21

820960-1	SWITCH OVERTEMPERATURE	21
820961-1	SWITCH OVERTEMPERATURE	21
820963-2	SENSOR DUCT TEMP	21
820964-1	SENSOR ABSOLUTE PRESSURE	21
820965-1	SENSOR DIFFERENTIAL PRESSURE	21
820966-1	SHUTOFF VALVE EJECTOR	79
820966-2	SHUTOFF VALVE EJECTOR	79
820967	VALVE COMPRESSOR CHECK	21
820967-1	VALVE COMPRESSOR CHECK	21
820967-2	VALVE COMPRESSOR CHECK	21
820971-2	VALVE REGULATING SHUTOFF	36
820971-3	VALVE REGULATING SHUTOFF	36
820972-3	PRECOOLER HEAT EXCHANGER	36
820973-1	SWITCH PRESSURE	36
820973-2	SWITCH PRESSURE	36
820983	VALVE SHUT OFF	36
820983-1	VALVE SHUT OFF	36
820983-2	VALVE SHUT OFF	36
821168-2	ROTARY ACTUATOR	36
821168-3	ROTARY ACTUATOR	36
821337-1	VALVE CHECK	36
822-0393-001	RECEIVER VHF NAVIGATION	23
822-0615-312	ALTIMETER 2ND RADIO	34
822-0615-316	ALTIMETER 2ND RADIO	34
822645-1	UNIT ENGINE COCKPIT INTERFACE	31
82410240-003	EVACUATION PANEL ASSY	52
82410600-003	LANDING & TAXI LIGHT PANEL ASSY	33
82410601-003	AC CONTROL PANEL ASSY	31
82410601-951	AC CONTROL PANEL ASSY	31
82410602-005	DIMMER CONTROL PANEL ASSY	25
82410603-009	DC CONTROL PANEL ASSY	24

82410603-011	AC CONTROL PANEL ASSY	31
82410604-003	FIRE PROTECTION PANEL ASSY	26
82410605-019	ICE & RAIN PROTECTION PANEL ASSY	30
82410605-021	ICE & RAIN PROTECTION PANEL ASSY	30
82410605-023	ICE & RAIN PROTECTION PANEL ASSY	30
82410605-1967	ICE & RAIN PROTECTION PANEL ASSY	30
82410605-1969	ICE & RAIN PROTECTION PANEL ASSY	30
82410605-999	ICE & RAIN PROTECTION PANEL ASSY	30
82410606-007	ANTI COLLISION LIGHT PANEL ASSY	33
82410607-007	ENGINE START CONTROL PANEL ASSY	72
82410607-969	ENGINE START CONTROL PANEL ASSY	72
82410608-005	AIRLERON RUDDER TRIM PANEL ASSY	27
82410608-007	AIRLERON RUDDER TRIM PANEL ASSY	27
82410608-009	AIRLERON RUDDER TRIM PANEL ASSY	27
82410610-007	PANEL HYD - FLAP OVERRIDE CONTROL	29
82410610-009	PANEL HYD - FLAP OVERRIDE CONTROL	29
82410611-005	APU CONTROL PANEL ASSY	49
82410613-007	PILOT CONSOLE PANEL ASSY	31
82410615-003	ADVISORY PASSENGER WARNING PANEL ASSY	23
82410615-005	ADVISORY PASSENGER WARNING PANEL ASSY	23
82410615-007	ADVISORY PASSENGER WARNING PANEL ASSY	23
82410616-003	PILOT CONSOLE PANEL ASSY	31
82410619-011	ICE & RAIN PROTECTION PANEL ASSY	30
82410643-103	PILOT CONSOLE PANEL ASSY	31
82410705-003	PANEL FLIGHT DATA RECORDER	23
82410866-003	FUEL ENGINE CONTROL PANEL ASSY	28
82410866-005	FUEL ENGINE CONTROL PANEL ASSY	28
82410866-009	FUEL ENGINE CONTROL PANEL ASSY	28
82410866-955	FUEL ENGINE CONTROL PANEL ASSY	28
82410866-961	FUEL ENGINE CONTROL PANEL ASSY	28
82410909-009	AIR CONDITIONING PANEL ASSY	21
82410909-013	AIR CONDITIONING PANEL ASSY	21

82410924-003	ANTI COLLISION & TAIL LIGHT PANEL ASSY	33
82410924-007	ANTI COLLISION LIGHT PANEL ASSY	33
82410924-009	ANTI COLLISION LIGHT PANEL ASSY	33
82411036-001	PFD ALTIMETER PANEL ASSY	31
82560211-005	FDR & ELT PANEL ASSY	23
82560211-009	FDR & ELT PANEL ASSY	23
82910011-005	PUMP	29
82910012-017	RESERVOIR ASSY	29
82910012-021	RESERVOIR ASSY	29
83221002-011	DOOR LATCH ASSY	32
849557	HYDRAULIC PUMP	29
85210097-005	NEWEL UPPER	57
85127725-003	ROD ASSY	52
85127726-003	ROD ASSY	52
85127727-001	LINK ASSY	52
85127727-002	LINK ASSY	52
85216941-001	PIVOT ASSY TRANSLATION DOOR	52
85216941-002	PIVOT ASSY TRANSLATION DOOR	52
85216943-002	CRANK ASSY TRANSLATION DOOR	52
85216945-001	ROD ASSY TRANSLATION DOOR	52
85217065-001	ROD ASSY PUSH	52
85217602-003	HINGE ASSY AFT PAS DOOR	52
85217602-004	HINGE ASSY AFT PAS DOOR	52
85217724-003	ROD ASSY HANDLE	52
85217725-003	ROD ASSY HANDLE	52
85217756-003	HOOK ASSY AFT PASSENGER DOOR	52
85217756-005	HOOK ASSY AFT PASSENGER DOOR	52
85217802-001	DOOR ASSY VENT	52
85217802-002	DOOR ASSY VENT	52
85227020-001	ROD ASSY MODE SELECT HANDLE	52
85227021-001	ROD ASSY MODE SELECT HANDLE	52
85237602-001	LINK ASSY UPPER HINGE	52

85237602-003	LINK ASSY UPPER HINGE	52
85237603-001	LINK ASSY UPPER HINGE	52
85237603-003	LINK ASSY UPPER HINGE	52
85237636-001	LINK ASSY UPPER HINGE	52
85237636-003	LINK ASSY UPPER HINGE	52
85237671-013	ROD ASSY LATCH AFT BAG DOOR	52
85237671-015	ROD ASSY LATCH AFT BAG DOOR	52
85237671-017	ROD ASSY LATCH AFT BAG DOOR	52
85237671-019	ROD ASSY LATCH AFT BAG DOOR	52
85237671-021	ROD ASSY LATCH AFT BAG DOOR	52
85237671-023	ROD ASSY LATCH AFT BAG DOOR	52
85237811-003	LEVER ASSY COUNTER BALANCE	27
85780409-001	ROLLER FITTING ASSY	27
85780409-002	ROLLER FITTING ASSY	27
863800-00	COUPLER WEATHER RADAR	34
860TS09Y00	PANEL LANDING GEAR CONTROL	32
88060B010003	VALVE OUTFLOW AFT	21
88060B010103	VALVE OUTFLOW AFT	21
8-800-70-029	POWER AMPLIFIER	23
8-832-01-008	ACTIVE NOISE CONTROL UNIT	23
8-821-02-014	BOX CIRCUIT BREAKER	23
8SC5005-003	DUAL DISTRIBUTING VALVE	30
8SC0800-001	DUAL DISTRIBUTING VALVE	30
8SC0800-003	DUAL DISTRIBUTING VALVE	30
8SC0840-007	OIL COOLER	79
8SC0840-009	OIL COOLER	79
8SC0844-005	ACTUATOR EXIT DOOR	52
8SC1173-3	VALVE VENT SHUT OFF	21
8SC1352	BATTERY 40AH	24
8TJ126GAT2	FUEL FLOWMETER	73
8Z4638-001	PANEL CONTROL HYDRAULIC FLAP	27
8Z6819-001	PANEL AILERON RUDDER TRIM	57

900094-5	ACCUMULATOR HYDRAULIC	29
900095-1	ACCUMULATOR HYDRAULIC	29
913B010001	FWD SELECTOR	21
92146A010401	CABIN PRESSURE CONTROLLER	21
92147A020103	PANEL CABIN PRESSURE CONTROL	21
92148C010101	CABIN INDICATION CONTROL PANEL	21
945169-5	MANIFOLD FILTER HYDRAULIC	29
945169-6	MANIFOLD FILTER HYDRAULIC	29
945169-7	MANIFOLD FILTER HYDRAULIC	29
945170-3	MANIFOLD FILTER HYDRAULIC	29
9527102-501	CONTROLLER REMOTE ACCESS	31
96042-01	ENGINE VIBRATION ISOLATION SYSTEM	72
96042-05	ENGINE VIBRATION ISOLATION SYSTEM	72
96042-06	ENGINE VIBRATION ISOLATION SYSTEM	72
96042-08	ENGINE VIBRATION ISOLATION SYSTEM	72
96042-09	ENGINE VIBRATION ISOLATION SYSTEM	72
96042-10	ENGINE VIBRATION ISOLATION SYSTEM	72
960441-7	RESERVOIR HYD SYSTEM 1 - RH	29
960442-7	RESERVOIR HYD SYSTEM 2 - RH	29
960443-5	RESERVOIR HYD SYSTEM 3 - LH	29
960443-7	RESERVOIR HYD SYSTEM 3 - LH	29
960443-9	RESERVOIR HYD SYSTEM 3 - LH	29
965-0758-001	COMMUNICATION MANAGEMENT UNIT	23
965-0976-040-214-214	GROUND PROXIMITY WARNING COMPUTER	34
965-0976-040-218-218	GROUND PROXIMITY WARNING COMPUTER	34
965-0976-040-222-222	GROUND PROXIMITY WARNING COMPUTER	34
975237-3	HYDRAULIC FIREWALL SHUTOFF VALVE	29
975247-5	VALVE SELECTOR POWER TRANSFER	29
975247-7	VALVE SELECTOR POWER TRANSFER	29
975247-9	VALVE SELECTOR POWER TRANSFER	29
975248-3	VALVE ASSY FIREWALL	29
975250-3	VALVE HEAT EXCHANGER BYPASS	21

975250-7	VALVE HEAT EXCHANGER BYPASS	21
975253-5	VALVE ASSY ISOLATION	29
975254-2	VALVE CHECK	29
975256-3	VALVE RELIEF	29
975256-5	VALVE RELIEF	29
975257-5	VALVE ISOLATION	29
975257-9	VALVE ASSY	29
975266-3	HYDRAULIC FIREWALL SHUTOFF VALVE	29
975306-1	HYDRAULIC FIREWALL SHUTOFF VALVE	29
98070-1	VALVE FILL	25
980-4700-027	DFDR	31
980-6022-011	CVR	23
980-6116-004	MICROPHONE MONITOR	23
9C35-3	PUMP ASSY	28
9C36-1	PUMP ASSY	28
9C37-3	PUMP ASSY	28
ACP2531AC02	AUDIO CONTROL UNIT	23
AH2542AT03	HANDSET PASSENGER ADDRESS	23
AK2542CL04	KEYBOARD	23
AV24B1428-1	HYDRAULIC FIREWALL SHUTOFF VALVE	29
AV24B1445-1	HYDRAULIC FIREWALL SHUTOFF VALVE	29
AV24B1461	HYDRAULIC FIREWALL SHUTOFF VALVE	29
AV24B1461-3	HYDRAULIC FIREWALL SHUTOFF VALVE	29
C12424AE	FLIGHT GUIDANCE CONTROL PANEL	22
C12427AE	ESID CONTROL PANEL	31
C12428DD	EFIS CONTROL PANEL	31
C12429AA07	FLIGHT GUIDANCE COMPUTER	22
C12429AA08	FLIGHT GUIDANCE COMPUTER	22
C12431AB	PROCESSOR INPUT & OUTPUT	31
C12432AA06	PROCESSOR INPUT & OUTPUT	31
C12838BA	ICP CONTROL PANEL	31
C12844AB	CABINET INTEGRATED FLIGHT	31

C12842AB07	STALL PROTECTION MODULE	27
C12853AA	MODULE AIRCRAFT CONFIGURATION	31
C14135BB	PROBE AIR DATA LH	34
C14135CA	PROBE AIR DATA RH	34
C14135DA	PROBE AIR DATA LH	34
C148656-1	FLAP POWER UNIT	27
C148659-1	ACTUATOR FLAP N1 & N2	27
C148659-2	ACTUATOR FLAP N1 & N2	27
C148660-1	ACTUATOR FLAP N3	27
C148660-2	ACTUATOR FLAP N3	27
C148661-1	ACTUATOR FLAP N4	27
C148661-2	ACTUATOR FLAP N3	27
C148665-1	FLAP POSITION TRANSDUCER	27
C148674-2-003	FLAP CONTROL UNIT	27
C148674-2-005	FLAP CONTROL UNIT	27
C148675-3	FLAP POSITION INDICATOR UNIT	27
C153534-1	TRANSMISSION SHAFT N1	27
C153534-2	TRANSMISSION SHAFT N8	27
C153535-1	TRANSMISSION SHAFT N2	27
C153535-2	TRANSMISSION SHAFT N3	27
C153535-3	TRANSMISSION SHAFT N5	27
C153535-4	TRANSMISSION SHAFT N7	27
C153536-1	TRANSMISSION SHAFT N4	27
C153536-2	TRANSMISSION SHAFT N6	27
C153536-3	TRANSMISSION SHAFT N9	27
C16193AC	PROBE STANDBY AIR DATA	34
C16193BA	PROBE STANDBY AIR DATA	34
C16221AA02	INTEGRATED STANDBY INDICATOR	34
C16268AB	INDICATOR RUDDER TRIM	27
C16269AB	INDICATOR AIRLERON TRIM	27
C17053AC03	COMPUTER AIR DATA	34
C17061AB	POWER SUPPLY PRIME MODULE	31

C18111AA	PITCH ACTUATOR	22
C18112AA	YAW DAMPER ACTUATOR	22
C18117AA	PITCH ACTUATOR	22
C19190AB07	EFIS DISPLAY	34
CAU3932AE04	UNIT AUDIO REMOTE CONTROL	23
CDU3933AE05	AUDIO RADIO CONTROL DISPLAY UNIT	23
CDU3933AE04	AUDIO RADIO CONTROL DISPLAY UNIT	23
CDU3933AF05	AUDIO RADIO CONTROL DISPLAY UNIT	23
CDU3933AG05	AUDIO RADIO CONTROL DISPLAY UNIT	23
D2887-350C	THERMAL BYPASS VALVE KIT	79
D2887-715A	OIL COOLER	79
D2887-815A	OIL COOLER	79
D2887-915A	OIL COOLER AIR COOLED NACELLE	79
EVR716-11-300A	VHF COM	23
ECCX-1002-003	FLIGHT ATTENDANT PANEL	25
KCA0105W	STANDBY COMPASS	34
IS4Q7900001-101	OIL COOLER AIR COOLED NACELLE	79
FE278-004	INDICATOR ELEVATOR TRIM	27
FE279-001	PARKING BRAKE QUADRANT	76
FE280-004	QUADRANT POWER	76
FE281-002	QUADRANT CONDITION	76
FE282-004	FLAP CONTROL MODULE	76
FE289000000	LOAD LIMITER ELEVATOR	76
GMT4190-020	CLOCK DIGITAL	31
G-4304F	GAUGE CHARGING MANIFOLD	29
HA2542AR05	FWD HANDSET ASSY	23
HFE95-20D10	COFFEE MAKER (ESPRESSO)	25
LA11A2104	ACTUATOR	71
MC10-04-110	MASK AND REGULATOR ASSY	35
MPEV3-011-25C	HYDRAULIC MOTOR PUMP	29
MPEV3-011-25D	HYDRAULIC MOTOR PUMP	29
MPP6CC-2-03	HYDRAULIC POWER TRANSFER UNIT	29

MXP601	OXYGEN MASK STOWAGE BOX	35
NP157901-19	WINDSHIELD LH	56
NP157901-21	WINDSHIELD LH	56
NP157901-20	WINDSHIELD RH	56
NP157901-22	WINDSHIELD RH	56
S1821502-02	EMERGENCY LOCATOR TRANSMITTER	25
S1821502-03	EMERGENCY LOCATOR TRANSMITTER	25
SC06B001-109-01	CONVERTER CONTROL	24
ST01200SE	COCKPIT DOOR REINFORCED	52
PA4028AB01	PA AMPLIFIER	23
PAS3921AB02	BOARDING MUSIC SYSTEM	23
R95-3WRI	DISTRIBUTION DAMPER VALVE	27
RD-AX7675-51	PRE RECORDED ANNOUNCEMENT MACHINE	23
RS1267-3	MOTOR STEERING HYDRAULIC	29

